

# **Network Manager 3.0.0 (full version)**

## **Technical documentation**

**Katarzyna Wladyszewska, Hadden Sp.J.**

---

# **Network Manager 3.0.0 (full version): Technical documentation**

by Katarzyna Wladyszewska

Published April 2010

Copyright © 2003-2010 Hadden Sp.J.

HADDEN MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MANUAL, INCLUDING, BUT NOT LIMITED TO, THE WARRANTY OF DESIGN, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

All rights reserved. No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of Hadden Sp.J.

All trademarks included in this document are the property of their respective owners.

---

---

---

---

# Table of Contents

1. Conventions .....	1
2. General information about David system .....	2
2.1. General .....	2
2.2. David system architecture .....	3
3. Terminology .....	6
3.1. Authorization process made by David system products .....	6
3.2. David system terminology used in the documentation .....	6
4. Installation .....	7
4.1. The main configuration file of David system .....	7
4.2. Dedicated account for service of David system .....	7
4.3. Directories of David system .....	8
4.4. Configuration of syslogd daemon .....	8
5. Network Manager requirements .....	9
6. Installation .....	10
6.1. Installation from RPM package .....	10
6.2. Installation from the script .....	10
7. Network Manager (NM) .....	11
7.1. Functionality .....	11
7.2. Description .....	12
7.3. Related articles .....	12
8. Network Management Map Client (dnmmc) .....	14
8.1. General .....	14
8.2. Synopsis .....	14
8.3. Options .....	14
8.4. Request argument meaning .....	14
8.5. An answer format on requests .....	16
8.6. Description .....	17
8.7. Related articles .....	18
9. Service of Network Management Map (dnmmsd) .....	19
9.1. General .....	19
9.2. Synopsis .....	19
9.3. Options .....	19
9.4. The Database objects .....	20
9.5. Description .....	21
9.6. Client service .....	22
9.7. Service of the Database objects .....	22
9.8. Input parameters passed on netinterface-alarm.sh program .....	24
9.9. Input parameters passed on bgppeer-alarm.sh program .....	25
9.10. Input parameters passed on mitem-alarm.sh program .....	26
9.11. Input parameters passed on ping-alarm.sh program .....	26

9.12. Related articles .....	27
10. Enhanced Data Collector (dedcd) .....	28
10.1. General .....	28
10.2. Synopsis .....	28
10.3. Options .....	28
10.4. Description .....	28
10.5. Related articles .....	29
11. Slow Query Executor (dsqed) .....	30
11.1. General .....	30
11.2. Synopsis .....	30
11.3. Options .....	30
11.4. Description .....	30
11.5. Related articles .....	30
12. Network Management Map (xdnmm) .....	32
12.1. General .....	32
12.2. Synopsis .....	32
12.3. Options .....	32
12.4. Description .....	32
12.4.1. Starting up and terminating the application .....	32
12.4.2. Main window work .....	33
12.5. A configuration of the Database items .....	42
12.5.1. Styles configuration .....	42
12.5.2. A configuration of state groups .....	44
12.5.3. Communities configuration .....	46
12.5.4. Collection groups configuration .....	49
12.5.5. Managed item groups configuration .....	54
12.5.6. Layers configuration .....	63
12.5.7. Network interfaces configuration .....	64
12.5.8. BGP peers configuration .....	68
12.5.9. Managed item configuration .....	70
12.5.10. Objects configuration .....	73
12.5.11. A configuration of ping object groups .....	78
12.5.12. Item alarms configuration .....	80
12.5.13. Item states configuration .....	81
12.5.14. A configuration of a user and an item group .....	81
12.5.15. A configuration of additional groups of item .....	82
12.5.16. A configuration of access rights to the Database objects .....	83
12.6. Description of ping object panels .....	84
12.7. A window presenting a list of logged in users on dnmsd server .....	87
12.8. A configuration of xdnmm application .....	88
12.8.1. A configuration of dnmsd server parameters .....	88
12.8.2. A Read-Only mode configuration .....	89
12.9. Related articles .....	89
13. Network Nodes Viewer (xdnvv) .....	90
13.1. General .....	90

13.2. Synopsis .....	90
13.3. Options .....	90
13.4. Description .....	91
13.4.1. Sessions statistics .....	93
13.4.2. A basic timer list tab .....	93
13.4.3. Counters tab .....	94
13.4.4. Sessions and PDU-s tab .....	94
13.4.5. Timeouts tab .....	95
13.5. Related articles .....	95
14. Network Node Views Editor (xdnve) .....	96
14.1. General .....	96
14.2. Synopsis .....	96
14.3. Options .....	96
14.4. Description .....	96
14.4.1. Starting up and terminating the application .....	96
14.4.2. Main window work .....	97
14.5. Main panel configuration .....	99
14.6. Configuration of controls common properties .....	101
14.6.1. Main tab .....	102
14.6.2. Style tab .....	103
14.6.3. Actions tab .....	104
14.6.4. Frame tab .....	106
14.6.5. Tabs for particular controls .....	106
14.7. Specific tabs for particular type of controls .....	107
14.7.1. The Specific tab for Line edit control .....	107
14.7.2. The Specific tab for Label control .....	108
14.7.3. The Specific tab for Push button control .....	108
14.7.4. The Specific tab for Progress bar control .....	109
14.7.5. The Specific tab for Check box control .....	110
14.7.6. The Specific tab for Combo box control .....	110
14.7.7. The Specific tab for Group box control .....	111
14.7.8. The Specific tab for List box control .....	112
14.7.9. The Specific tab for Radio button group control .....	113
14.7.10. The Specific tab for Scroll bar control .....	113
14.7.11. The Specific tab for Slider control .....	114
14.7.12. The Specific tab for Spin box control .....	115
14.7.13. The Specific tab for List view control .....	116
14.7.14. The Specific tab for LCD number control .....	119
14.7.15. The Specific tab for Graph control .....	119
14.7.16. The Specific tab for Control light control .....	120
14.7.17. The Specific tab for Line control .....	121
14.8. Related articles .....	122
15. Buttons the most often used in Web applications .....	123
15.1. The buttons meaning .....	123
16. Excluded IP Address Configurator .....	125

16.1. General .....	125
16.2. Description .....	125
16.3. Related articles .....	126
17. SNMP Community Configurator .....	127
17.1. General .....	127
17.2. Description .....	127
17.3. Related articles .....	128
18. User and Group Manager .....	129
18.1. General .....	129
18.2. Description .....	129
18.3. Related articles .....	129
19. User Manager .....	130
19.1. General .....	130
19.2. Description .....	130
19.3. Related articles .....	132
20. Group Manager .....	133
20.1. General .....	133
20.2. Description .....	133
20.3. Related articles .....	134
21. Collection Browser .....	135
21.1. General .....	135
21.2. Description .....	135
21.2.1. The index of available collections .....	135
21.2.2. The view of collection graphs .....	136
21.3. Related articles .....	137
22. Node Browser .....	138
22.1. General .....	138
22.2. Description .....	138
22.2.1. Tree view tab .....	138
22.2.2. Accounting tab .....	146
22.3. Related articles .....	150
23. Node Reporter .....	151
23.1. General .....	151
23.2. Description .....	151
23.2.1. Specyfication of searching criterions .....	151
23.2.2. A specyfication of report components for given items .....	153
23.2.3. Generated report .....	156
23.3. Related articles .....	157
24. Notification Recipient Configurator .....	158
24.1. General .....	158
24.2. Description .....	158
24.3. Related articles .....	159
25. Web Module Configurator .....	160
25.1. General .....	160
25.2. Description .....	160

25.3. Related articles .....	161
26. Service Monitor .....	163
26.1. General .....	163
26.2. Description .....	163
26.3. Related articles .....	164
27. Customer Configurator .....	165
27.1. General .....	165
27.2. Description .....	165
27.2.1. Customers tab .....	165
27.2.2. Customer groups tab .....	171
27.3. Related articles .....	174



---

## List of Tables

1.1. The typographical conventions used in this manual .....	1
2.1. David system products .....	3
8.1. dnmmc options .....	14
8.2. Request argument meaning .....	15
9.1. dnmsd options .....	19
10.1. dedcd options .....	28
11.1. dsqed options .....	30
12.1. xdnmm options .....	32
12.2. xdnmm - the status bar buttons .....	34
12.3. xdnmm - the File menu buttons .....	35
12.4. xdnmm - File menu buttons which aren't placed on the toolbar .....	35
12.5. xdnmm - the Edit menu buttons .....	36
12.6. xdnmm - Edit menu options which aren't placed on the toolbar .....	36
12.7. xdnmm - View menu buttons .....	37
12.8. xdnmm - the View menu buttons, that aren't placed on the toolbar .....	38
12.9. xdnmm - the David system menu buttons .....	38
12.10. xdnmm - hierarchical maps of objects buttons .....	41
12.11. Meaning of Operation field in Community window .....	47
12.12. The work results of two Communities depending on Operation field .....	48
12.13. Communities dialog - description of the buttons .....	49
12.14. Types of the collection groups .....	50
12.15. Values of Style field for variables of collection group .....	52
12.16. Values of the field Accounting type for variables of collection group .....	53
12.17. A description of the Collect groups buttons .....	53
12.18. Values of Type field for entries of managed item group .....	57
12.19. The Unit field values for entries of the managed item group .....	59
12.20. Style field values for entries of the managed item group .....	59
12.21. Values of the field Accounting type for entries of managed item group .....	60
12.22. Values of Destination type field for Link tab of managed item group .....	62
12.23. The buttons of Managed item groups dialog .....	63
12.24. A description of the Ping groups window buttons .....	80
12.25. Description of Logged in users window buttons .....	87
13.1. xdnnv options .....	90
13.2. xdnnv - File and Utilities menu buttons .....	92
14.1. xdnnve options .....	96
14.2. xdnnve - File menu buttons .....	97
14.3. xdnnve - Edit menu buttons .....	98
14.4. Sessions group buttons .....	100
14.5. Description of the controls .....	101
14.6. Tabs for particular controls .....	106
15.1. The buttons the most often used in Web applications .....	123

20.1. Group Manager - meaning of user group fields .....	133
21.1. Collection Browser - the toolbar buttons .....	136
21.2. Collection Browser - the toolbar buttons .....	137
22.1. Node Browser - Tree view columns .....	138
22.2. Node Browser - the other columns of Tree view tab .....	139
22.3. Node Browser - Tree view buttons .....	141
25.1. Web Module Configurator - meaning of the application fields .....	160
26.1. Service Monitor - meaning of the application fields .....	163
27.1. Customer Configurator - columns of the application .....	170

---

# Chapter 1. Conventions

The following typographical conventions are used in this manual:

**Table 1.1. The typographical conventions used in this manual**

Font	What the font represents	Example
<i>Italic</i>	Environment variables.	The name is kept in environmental variable <i>\$DAVIDPRIVDIR...</i>
<i>Italic</i>	Synopsis options.	<i>[-l,--log-facility log_facility]</i>
<b>Bold</b>	Names of programs and products.	<b>damcsud</b> is a part of <b>Operation Manager-a</b> .
Computer	Names of options and menus.	There is Show tool bar option in View menu.
Computer	Names of files and directories.	... reads its configuration file <code>.damadbudrc</code> .
Computer	Names of windows and dialog fields.	In A sessions property window, in Sticking string field, you can write...
Computer	Names of buttons.	Pressing Apply button lets you apply changes.
<b>Computer Bold</b>	Math formulas.	<b><math>\exp(-x)</math></b> , when $a = 0$ <b><math>1 / \text{pow}(a, a) * \text{pow}(x, a) * \exp(-x + a)</math></b> , when $a > 0$ .
<b>Computer Bold</b>	Terms used in David system terminology.	<b>SNMP Data</b> - a kind of data...
<b>Computer Bold</b>	Contents of configurations files.	<b>action</b> <b>{</b> <b>...</b> <b>}</b>

---

# Chapter 2. General information about David system

## 2.1. General

**David system** is a network management system. It is a packet of applications (modules) that allows computer network to be monitored and managed in real-time through the Internet. There is only one condition that managed devices must meet. Each device must provide SNMP (Simple Network Management Protocol) service. SNMP is the most common management protocol in the Internet so that requirement shouldn't be difficult to meet. Here is the list of typical devices that can be monitored:

- IP routers,
- ATM switches,
- manageable ethernet switches,
- UPSes with a SNMP adapter,
- TV-SAT modems that allow IP devices to work in TV cable networks,
- computers.

One of the most important feature of **David system** is its architecture. It's built of high level configurable and independent from one another modules. This principle is the most essential rule of the project. In consequences, in th metter of speaking, the same modules may build different management system. Here are the main features of **David system**:

- general thinking in information flow controlling that come form high level independence of modules of the system,
- high level configureability of the system modules that allows a special configuration of **David system** to reach end-user expectations so close as it's only possible,
- the system scalability, so you can build up the system adding additional modules in very easy way; note that these modules needn't to be part of **David system** at all; adding another monitored devices to the system is a very easy procedure,
- using shell scripts in information processing is opportunity for modeling information and influence on processing it,
- all configuration files of **David system**, files with input/output data and log files are text files,

- using SNMPv1, SNMPv2C and SNMPv3 to communicate with monitored devices.

## 2.2. David system architecture


**Table 2.1. David system products**

Product	Description
David system Common Files	The product, during its installation, prepares the rudimentary directory tree for other products of <b>David system</b> . It also contains some essential and common files for all the products. Thus, this is a fundamental product of <b>David system</b> required by other its products.
Primary SQL Database	The product installs the primary SQL database of <b>David system</b> . Every single installation of <b>David system</b> must have only one the primary database.
Secondary SQL Database	The product installs the secondary SQL database of <b>David system</b> . Each installation of <b>David system</b> may have many secondary databases or none. It allows to distribute the SQL database of <b>David system</b> among many servers.
David system Libraries	This product provides libraries of <b>David system</b> required by its applications. Many other products of <b>David system</b> require that one.
Daemon Manager	It engages in running and terminating daemons of <b>David system</b> as well as monitoring of their work.
Network Manager (full version)	The product using SNMP protocol allows to visualise a topology of monitored networks and auto-discover devices in managed networks. The state of monitored devices also is visualized. The product also collects data from monitored devices using SNMP protocol and allows you to manage user accounts.
Network Manager (console version)	The product, through a graphic application, allows to visualize a topology of monitored networks and shows states of monitored resources. It allows you to control daemons monitoring devices as well as that ones gathering data. Currently, most of functions of that application is obtainable through web applications.
Notification Processor	The product chiefly engages in processing SNMP Trap notifications coming from monitored devices to management stations. The received messages can be formatted to the human readable forms, and then recorded as well. The processed notifications can be passed on to future processing.
Operation Manager (full version)	It can run specified actions on the basis of received data. Sophisticated estimation process depends on information coming from other products of <b>David system</b> and correlation of that information. It tries to build more intelligent and useful notifications then just simple reactions to incoming

## General information about David system

Product	Description
	events. The graphic application displays notifications about received events and allows to play audio files as well as reading messages by an outer speech synthesizer.
Operation Manager (console version)	The product contains a graphic application displaying notifications about events and allowing to play audio files as well as reading messages by an outer speech synthesizer.
Report Manager	The product processes recorded SNMP Trap notifications, entries about pending operations and entries about state changes of monitored devices (ping objects, network interfaces and BGP peers), and generates reports on the basis of them. Reports can be viewed using a Web application.
Service Monitor	The product monitors selected network services on application level. In order to do this it monitors selected TCP ports of specified hosts. It checks both availability of ports and a correct reaction for a few selected network protocols (HTTP, SMTP, FTP). It also can verify correctness of work of selected services by verification of received data. Results of its work can be viewed as reports and graphs made available by a Web application.
SQL Database Archive and Backup Manager	It archives the SQL Database used by <b>David system</b> applications.
Distributed SQL Database Manager	It allows to divide the database of <b>David system</b> into one primary database and many secondary ones. Such step boosts performance of the system and decreases load of the servers where daemons of <b>David system</b> work. The migration takes place during the routine work of the system. Such division may be altered many times.

Dependencies between the **David system** products are shown on the following chart..



**David system** functionality can be very large and it depends on particular configuration a lot. The most important features of **David system** are:

- discovering and visualization of monitored networks topology including visualization of states of

particular nodes;

- possibility of building control panels to monitored devices (they must support SNMP protocol), regardless of device providers;
- formatting and recording SNMP Traps sent by agents working on monitored devices;
- automatic reaction to specified SNMP Traps received from monitored devices;
- possibility of identification of an operator that has received an alert from the system about a problem;
- collecting data concerning parameters of monitored devices;
- automatic reaction to incorrect values of data that were found during data collecting;
- recording pending cases, processed by the system, which have been created as responses for events detected by the system in a monitored network;
- monitoring selected network services on application level.

---

# Chapter 3. Terminology

## 3.1. Authorization process made by David system products

The modules of David system which need to do an authorization of message senders (i.e. **damsnmpdaud**, **dnmmsd**, **dgnsd**), use the library, that checks whether an IP address of a sender matches with any record found in the file `.known.host`. The library expects to find the file in a directory pointed by a variable `confdir` in the file `/etc/system-david.conf`.

Records in the file `.known.host` are regular expressions specifying acceptable IP addresses.

## 3.2. David system terminology used in the documentation

There is an explanation of some terms, that are used in David system and its documentation:

- **messages (information)** - data received by interfaces of **Operation Manager**, its data analysers and **Cases Database Unit** of the product.
- **notifications** - the term often is used in the products: **Notification Processor**, **Operation Manager** and **Report Manager**; There are mostly data, that a source are SNMP agents working on network monitored devices.
- **events** - the term often is used in the products: **Operation Manager** and **Report Manager**; and it describes a being, that a source is SNMP Trap or SNMP Data; an **event** is always a part of a **case**;
- **cases** - the term often is used in the products: **Operation Manager** and **Report Manager**; and it describes a group of events connected one another; one **event** at last must be included in a **case**;
- **SNMP Trap** - a kind of data of **Operation Manager** product, which a source are received responses from SNMP agents; SNMP Traps aren't answers on the requests sent by a management station, but they are sent by agents managing network interfaces and processed by **Notification Processor** product;
- **SNMP Data** - a kind of data of **Operation Manager** product, which a source are received responses from SNMP agents on request which a management station sent to them by **Network Manager**.



---

# Chapter 4. Installation

## 4.1. The main configuration file of David system

The essential configuration file of David system is `/etc/david-system.conf`. It contains entries as pairs: `key = value`. Basically, except the entry `default_email_recipient`, there is no such need to modify any record in that file. All necessary modifications are made during installation processes of particular David system products. Below, there is a list of all entries along with their descriptions that may occur in this basic configuration file.

- `user` - a name of the user with which rights all daemons of David system works;
- `default_email_recipient` - the default e-mail address where messages from David system applications are sent;
- `bindir` - the directory containing David system applications (default: `/usr/bin/david-system`);
- `libdir` - the directory containing David system libraries (default: `/usr/lib/david-system`);
- `incdir` - the directory containing David system headers (default: `/usr/include/david`);
- `confdir` - the directory containing David system configuration files (default: `/etc/david-system`);
- `logdir` - the directory containing log files of David system applications (default: `/var/log/david-system`);
- `sharedir` - the directory containing various files (images, audio files, web files) of David system (default: `/usr/share/david-system`);
- `docdir` - the directory containing various files (images, audio files, web files) of David system (default: `/usr/share/david-system`);
- `vardir` - the directory containing archive files of David system SQL database (default: `/var/lib/david-system`);
- `is_sqldb_installed` - the flag that indicates whether the SQL database of David system has been installed or not.

## 4.2. Dedicated account for service of David system

There is no need to run any David system module as superuser (usually an account `root` with UID equals 0). Even if some David system daemon requires root rights when starting, there is always possibility to specify, as one of the daemons starting arguments, a user that rights should be taken.

It is a good idea to add a new user to an operating system, under which control David system will work.

## 4.3. Directories of David system

This hierarchy depends on a particular configuration of David system. In the default system configuration, David system contains the following directories:

- `/usr/bin/david-system` - binaries and shell scripts;
- `/etc/david-system` - configuration files;
- `/usr/share/doc/david-system` - the documentation;
- `/usr/share/david-system` - graphic and audio files, web portal;
- `/usr/include/david` - David system header files;
- `/usr/lib/david-system` - David system libraries;
- `/var/log/david-system` - log files;
- `/var/lib/david-system` - archive files of the David system SQL database;

## 4.4. Configuration of syslogd daemon

David system modules use `syslog` subsystem available on UNIX platforms. Default configuration of the system modules causes that log messages are sent with `local6` facility. It may be changed for every module during its startup. Its recommended to configure `syslogd` daemon to write all messages from David system modules into one place (one or more files with characteristic name i.e.: `david.log`).

---

# Chapter 5. Network Manager requirements

The following requirements must be met by a management platform where **Network Manager** works:

- 512 MB of RAM and 1 GB of swap memory at least;
- at least 1.5 GHz CPU;
- HTTP server (eg. [Apache \(http://www.apache.org\)](http://www.apache.org));
- [PHP 4 interpreter \(http://www.php.net\)](http://www.php.net) (with a support for GD and MySQL libraries) as a module of web server;
- installed compatible version of **Daemon Manager**.

---

# Chapter 6. Installation

## 6.1. Installation from RPM package

You must be `root` to install the product. Following steps must be taken in order to install the product:

- Install the product:

```
rpm -i david-xxx-nm-f-yyy.rpm
```

## 6.2. Installation from the script

You must be `root` to install the product. Following steps must be taken in order to install the product:

- Uncompress and unpack the archive:

```
gunzip david-xxx-nm-f-yyy.i386.tar.gz  
tar xf david-xxx-nm-f-yyy.i386.tar
```

The operations create `david-xxx-nm-f-yyy.i386` directory in your current directory.

- Change your current directory to `david-xxx-nm-f-yyy.i386`:

```
cd david-xxx-nm-f-yyy.i386
```

- Read `LICENSE` file and **CONTINUE THE INSTALLATION, ONLY WHEN YOU ACCEPT ALL CONDITIONS INCLUDED IN THE LICENSE.**
- Run the installation script:

```
./install
```

---

# Chapter 7. Network Manager (NM)

## 7.1. Functionality

**Network Manager** makes possible:

- auto discovering of devices included in monitored networks and adding them to the managed device database;
- visualization of monitored network topologies according to data gathered from managed devices through SNMP protocol;
- monitored device states visualization (states of network interfaces, BGP sessions);
- visualization of responses of monitored devices for ICMP ECHO packets sent by the management station (similary as ping command);
- creation objects that represent service, node etc., which state depends on states of other objects and services stored in the database;
- running directly from presented topology maps the most suitable control panels for selected devices and other graphic applications of David system;
- designing graphic interfaces to control network devices that supply SNMP protocol; appearance of each interface and its functionality depend on an end-user invention (every control panel is written as a separate file);
- real-time monitoring (considering speed of computer networks and polling interval) of devices work parameters and controlling its work, through generated application - control interface to a particular device;
- visualization of network device work parameters through a generated application - interface to a particular device;
- collecting current parameters of monitored devices work using SNMP protocol;
- presenting collected data as graphs available in Web site;
- sending collected data to **Operation Manager**; it makes possible to detect potential problems in early phase.
- management of David system user accounts (creation and modification of user accounts).
- management of David system user groups (creation and modification of user groups and classifying user groups as selected groups);

- creation an access policy to component elements of the system for particular users and user groups.

## 7.2. Description

One of the assignments of **Network Manager** is discovered devices belong to managed networks, built topology maps of monitored networks and made visualization of discovered device states.

The product can gather information about networks from their nodes through SNMP protocol, and next it visualises the collected data through a graphic application which is a user friendly interface to the monitored network database.

An important assignment of the product is gathered current work parameters of network devices using SNMP protocol. The gathered data a user can see in the form of graphs by the Web browser. The collected data also are sent to **Operation Manager**.

**Network Manager**, on the base of its configuration files, can generate applications that are graphic interfaces that monitor work of devices on which SNMP agents work. Such interfaces usually show that parameters of devices, which are important in a given situation. Many interfaces to a particular device may exist at the same time (stored in separate files). The panels can be created and modified very easily by end-users. Main edition technique used to panels creation is, like in a different kind of graphic editors, using a mouse as main designed tool.

**Network Manager** is also responsible for management of user accounts. These users are quite independent of operating system users, on which operating system works. Each user has an username as its identifier, number (UID), privilege level (ULEVEL - zero means the highest level), password and description of the account (GECOS). Each user can belong to free number of user groups.

**Network Manager** is also responsible for management of user groups. Each group has an username. The groups allows to manage access rights to elements of David system in effective way.

## 7.3. Related articles

[Service of Network Management Map \(dnmmsd\)](#)

[Network Management Map Client \(dnmmc\)](#)

[Network Management Map \(xdnmm\)](#)

[Enhanced Data Collector \(dedcd\)](#)

[Network Nodes Viewer \(xdnnv\)](#)

[Network Node Views Editor \(xdnnve\)](#)

[Slow Query Executor](#)

[Excluded IP Address Configurator](#)

[SNMP Community Configurator](#)

[User Manager](#)

[User and Group Manager](#)

[Collection Browser](#)

[Node Browser](#)

[Node Report Browser](#)

[Notification Recipient Configurator](#)

[Web Module Configurator](#)

[Service Monitor](#)

[Customer Configurator](#)

---

# Chapter 8. Network Management Map Client (dnmmc)

## 8.1. General

**dnmmc** is **Network Management Map Client** and it is a part of **Network Manager**. It allows you to connect with the **Network Information Database** from shell level. The communication can depend on getting an answer to a request or doing an order.

## 8.2. Synopsis

**dnmmc** can be run with the following options: `[-l,--log-facility log_facility]` `[-L,--log-level log_level]` `[-f,--password-file filename]` `[-u,--user username]` `[-e,--enc-password]` `[-v,--version]` `[-h,--help]`

## 8.3. Options

Table 8.1. dnmmc options

Option name	Description
<code>-l,--log-facility log_facility</code>	Choose log facility: daemon   user   local0   ...   local7 (default: local6).
<code>-L,--log-level log_level</code>	Choose log level (on stderr and syslog) i.e. messages of selected level and more important levels will be logged: emerg   alert   crit   err   warning   notice   info   debug0   ...   debug2 (default: warning).
<code>-f,--password-file filename</code>	Specify a file (in \$DAVIDSECCONFDIR directory) containing username and password to login to the server (default: .nmmc.pwd).
<code>-u,--user username</code>	Login to the server as a specified user instead of a user taken from \$DAVIDSECCONFDIR/.nmmc.pwd file (password is read from stdin).
<code>-e,--enc-password</code>	Tell the server that the password is already encrypted.
<code>-v,--version</code>	Display version number on stderr and exit.
<code>-h,--help</code>	Display this help and exit.

## 8.4. Request argument meaning

A request from the below list is a required argument:



**Table 8.2. Request argument meaning**

Argument name	Description
pingobject-alarm-off-until-ok id	Turn off the alarm until the state is OK for a specified ping object.
pingobject-alarm-always-off id	Turn off the alarm for a given ping object.
pingobject-alarm-off id day sec	Turn of the alarm for a given ping object until a specified period of time comes.
pingobject-alarm-on id	Turn on the alarm for a given ping object.
<i>pingobject-test-alarm id</i>	Run a test alarm for a given ping object.
<i>netinterface-alarm-off-until-ok id</i>	Turn off alarm until a CRITICAL state is finished for a given network interface.
<i>netinterface-alarm-always-off id</i>	Turn off alarm for a given network interface.
<i>netinterface-alarm-off id day sec</i>	Turn off alarm for a given network interface until a specified period of time.
<i>netinterface-alarm-on id</i>	Turn on alarm for a given network interface.
<i>netinterface-test-alarm id</i>	Run a test alarm for a given network interface.
<i>bgppeer-alarm-off-until-ok id</i>	Turn off alarm until a CRITICAL state is finished for a given BGP peer.
<i>bgppeer-alarm-always-off id</i>	Turn off alarm for a given BGP peer.
<i>bgppeer-alarm-off id day sec</i>	Turn off alarm for a given BGP peer until a specified period of time.
<i>bgppeer-alarm-on id</i>	Turn on alarm for a given BGP peer.
<i>bgppeer-test-alarm id</i>	Run a test alarm for a given BGP peer.
<i>mitem-alarm-off-until-ok id</i>	Turn off alarm until a CRITICAL state is finished for a given managed item.
<i>mitem-alarm-always-off id</i>	Turn off alarm for a given managed item.
<i>mitem-alarm-off id day sec</i>	Turn off alarm for a given managed item until a specified period of time.
<i>mitem-alarm-on id</i>	Turn on alarm for a given managed item.
<i>mitem-test-alarm id</i>	Run a test alarm for a given managed item.
find-netinterface IP ifIndex	Find a network interface with a specified ifIndex on a given host.
find-bgp-peer IP peer	Find a BGP peer with a specified IP address on a given host.
find-object IP	Find a host with a given IP address.
<i>find-mitem IP table index</i>	Find a managed item with a specified ifIndex (OID or number) which belongs to a specified table (OID), on a given host.
is-community string community	Check if a given community is inside of a given string (you need no login to a server).

## 8.5. An answer format on requests

Answers of the request `find-netinterface IP ifIndex`:

- `ID`: a number identifier of the network interface;
- `OWNER ID`: a number identifier to which a network interface belongs to;
- `OWNER`: a host to which a network interface belongs to;
- `DESCRIPTION`: a network interface description;
- `ALIAS`: an alias of a network interface;
- `TYPE`: a type of a network interface;
- `ADMIN STATUS`: an administration status of a network interface;
- `OPER STATUS`: an operation status of a network interface;
- `SPEED`: bit rate (in B/sec.) of a network interface;
- `HIGH SPEED`: bit rate (in MB/sec.) of a network interface;
- `STATE`: a state of a network interface;
- `COMMUNITY`: a community of the network interface.
- `ALARM`: a current alarm for the network interface.

Answers of the request `find-bgp-peer IP peer`:

- `ID`: a number identifier of the BGP peer;
- `OWNER ID`: a number identifier to which a BGP peer belongs to;
- `OWNER`: a device to which a BGP peer belongs to;
- `REMOTE IP`: an IP address of a BGP peer;
- `DESCRIPTION`: a BGP peer description;
- `REMOTE AS`: a BGP peer AS;
- `ADMIN STATUS`: an administration status of a BGP peer;
- `OPER STATE`: an operation state of a BGP peer;

- STATE : a BGP peer state;
- COMMUNITY : community assigned to the BGP peer.
- ALARM : a current alarm for the BGP peer.

Answers of the request *find-mitem IP table index*:

- ID : a number identifier of the managed item;
- OWNER ID : a number identifier to which a managed item belongs to;
- OWNER : a device to which a managed item belongs to;
- MANAGED ITEM GROUP ID : a number identifier of source group for a managed item;
- MANAGED ITEM GROUP NAME : a name of source group for a managed item;
- STATE : a state of a managed item;
- COMMUNITY : a calculated community for the managed item;
- ALARM : a current alarm for the managed item.

Answers of the request *find-object IP*:

- NAME : an object name;
- SNMP COMMUNITY : SNMP community for read operation for the object;
- SNMP VERSION : SNMP version for the object;
- COMMUNITY : community assigned to the object.

## 8.6. Description

Program **dnmmc** makes possible a contact with **Network Information Database** from shell level. In a range of requires about doing operations **dnmmc** is an alternative solution to [Network Management Map](#), where you can make analogous operations. The module **dnmmc** lets you make only given operations in contrast to [Network Management Map](#), where a number of operations is essentially greater.

**dnmmc** allows you to realize requires about items of **Network Information Database** such as: network interfaces, BGP peers, managed devices and devices. The information is used by other modules of David system.

One request only don't require a contact with a server and it's the one that a given string includes a given `community` sequence. The option is added to keep an uniform access to a suitable library function. A return code of the module is zero when a given `community` doesn't exist in a given string and 1 if it exists.

A great part of **dnmmc** functionality is dictated the needs of access to David system through the Web.

## 8.7. Related articles

[Service of Network Management Map \(dnmmsd\)](#)

[Network Management Map \(xdnmm\)](#)

[Enhanced Data Collector \(dedcd\)](#)

---

# Chapter 9. Service of Network Management Map (dnmmsd)

## 9.1. General

**dnmmsd** is **Service of Network Management Map** and it is a part of **Network Manager**. It is a daemon process which works all the time the system is running and monitors work of devices inside a monitored network and makes information about these devices available to its clients i.e. graphic applications that want to display topology maps of monitored networks.

Owing to specific meaning of **dnmmsd** module many aspects of its functionality can be found inside the section dedicated to its graphic client which is [Network Management Map \(xdnmm\)](#).

## 9.2. Synopsis

**dnmmsd** can be run with the following options: [\[-i,--db-import filename\]](#) [\[-P,--pid-file filename\]](#) [\[-l,--log-facility log\\_facility\]](#) [\[-L,--log-level log\\_level\]](#) [\[-u,--run-as-user username\]](#) [\[--max-pings number\]](#) [\[--max-check-of-bgppeers number\]](#) [\[--max-check-of-netifs number\]](#) [\[--max-update-of-objects number\]](#) [\[--max-graphic-clients number\]](#) [\[--max-discovery-in-net number\]](#) [\[--socket-file-4-gc filename\]](#) [\[--port-4-gc port\]](#) [\[--buffer-ttl seconds\]](#) [\[--ping-status-expiration-time seconds\]](#) [\[--ping-down-status-expiration-time seconds\]](#) [\[--program-4-ping-alarm filename\]](#) [\[--node-2-discover host\]](#) [\[--background\]](#) [\[-v,--version\]](#) [\[-h,--help\]](#)

## 9.3. Options

Table 9.1. dnmmsd options

Option name	Description
<i>-i,--db-import filename</i>	Import <b>Network Information Database</b> from the specified file during startup.
<i>-P,--pid-file filename</i>	Write PID to a specified file.
<i>-l,--log-facility log_facility</i>	Choose log facility: daemon   user   local0   ...   local7 (default: local6).
<i>-L,--log-level log_level</i>	Choose log level (on stderr and syslog) i.e. messages of selected level and more important levels will be logged: emerg   alert   crit   err   warning   notice   info   debug0   ...   debug2 (default: notice).
<i>-u,--run-as-user username</i>	Drop root privileges and run server as a specified user.
<i>--max-pings number</i>	Maximum number of hosts that are pinged at the same time (default:

## Service of Network Management Map (dnmmsd)

Option name	Description
	5).
<i>--max-check-of-bgppeers number</i>	Maximum number of 'check BGP peer' requests generated at the same time (default: 5).
<i>--max-check-of-netifs number</i>	Maximum number of 'check net interface' requests generated at the same time (default: 5).
<i>--max-update-of-objects number</i>	Max number of 'update object' requests generated at the same time (default: 5).
<i>--max-graphic-clients number</i>	Specify maximum number of graphic clients that can be served at the same time (default: 10).
<i>--max-discovery-in-net number</i>	Discover (poll) no more than that number of nodes from one network at one time (default: 20).
<i>--socket-file-4-gc filename</i>	Wait for connections from graphic clients via a specified socket file (default: /tmp/dnmm.gc.socket).
<i>--port-4-gc port</i>	Listen to a specified TCP port waiting for graphic clients (default: use a socket file).
<i>--buffer-ttl seconds</i>	Specify a maximum TTL (time to live) for outgoing messages (default: 300).
<i>--ping-status-expiration-time seconds</i>	Specify a number of seconds (since the last update) after that a ping object status will be treated as expired at the startup (default: 300).
<i>--ping-down-status-expiration-time seconds</i>	Specify a number of seconds (since the last down state - 0% of responses) after that a ping object alarm will be turned on, if the appropriate flag is active (default: 900).
<i>--program-4-ping-alarm filename</i>	Specify a program called when ping alarm (less than 100% of responses) occurs (default: DAVIDDIR/bin/ping-alarm.sh).
<i>--node-2-discover host</i>	Specify a node from the discovery process should be begun instead of local network.
<i>--background</i>	Go to background after startup.
<i>-v,--version</i>	Display version number on stderr and exit.
<i>-h,--help</i>	Display this help and exit.

## 9.4. The Database objects

The following data types can occur in the **Network Information Database**:

- styles included in state groups;
- state groups owned by network interfaces, BGP peers, objects and ping objects;

- layers to which network interfaces, BGP peers, objects and ping objects belong (not used currently);
- network interfaces owned by such objects as computers or routers;
- BGP peers owned by objects as routers;
- objects (discovered devices and objects added by a user);
- ping objects;
- groups of ping objects.

Each of the above Database items has specific properties but also has common attributes as:

- an item creator identifier;
- an item modifier identifier;
- an item creation time;
- an item modification time;
- a minimum user level needed to change the item properties.
- an owner identifier and a group identifier;
- access rights (right to read, write and execute) of an owner and a group and other users;
- free number of additional groups with access rights to each of them.

Also adding and deleting any item of the Database are restricted by rights and have the same attributes as the above ones for particular items. Additionally, some items of the Database include another right attributes to their specific properties.

Objects, discovered during the module work and also that added by a user, can be arranged into hierarchical, parent-child, order. Thanks to that you can build hierarchy maps of monitored devices what helps you to keep control under all information you have. Only a user fully decides about hierarchy structure of managed objects.

## 9.5. Description

**dnmmsd** module is responsible for monitoring devices discovered in a managed network. As a result you can see a topology map of a monitored network. The module makes the gathered information about devices available to its clients. The graphic application [xdnmm](#) that presents topological maps of networks is one of the module client.

During startup of **dnmmsd** is run, it creates two child processes. The first one is responsible for sending and receiving ICMP-ECHO packets to monitored devices discovered by **dnmmsd** daemon and to IP addresses configured by a user. The second one serves SNMP requests sending to monitored devices discovered by **dnmmsd** daemon.

As next step the **Network Information Database** is loaded from a file specified as an argument of [-i,--db-import](#) option. The operation has one-time character i.e. an import of data will be done when **Network Information Database** is accepted as empty. In the end **dnmmsd** begins awaiting for clients' requests and monitoring of network management.

## 9.6. Client service

When **dnmmsd** waits for client requests sending through a network and receives a new connection attempt, then authorizes the client depending on IP address of the client. The authorization result depends on information included in the file `.known.hosts`. If the module can't open `.known.hosts` file for reading or the client's IP address doesn't match to any entry of the file, the connection is rejected. When the daemon waits for client requests through a socket file, the authorization is skipped. The new connection can be also rejected, when maximum number of connections is reached ([--max-graphic-clients](#) option).

After the successful acceptance of a new incoming connection a user-based authentication is prepared on the basis of **Users' Database** of David system.

After the successful login procedure the user can read and write data from and to the **Network Information Database**. Also the user can receive notifications about every change of any object in the Database. It reduces traffic and amount of operations between clients and the daemon because clients don't need to ask about each object state all the time.

Every client can login many times and each time as another user. A logged in user has rights according to the **Users' Database**. The users, besides operations on the Database that number exceeds one hundred, can do the following operations:

- log out;
- log out lower level users;
- list logged in users.

## 9.7. Service of the Database objects

In an initial phase of the module work, when the **Network Information Database** doesn't include any objects discovered by **dnmmsd** yet, the discovering procedure can be begun on two ways:



- by polling a particular device specified as one of running options ([--node-2-discover](#) option);
- by discovering a local network, inside which the management station works.

The discovering procedure can be omitted for addresses specified in the [configuration of addresses excluded from the discovering procedure](#). Devices are discovered by sending SNMP requests to particular IP addresses. The IP addresses are another addresses belonging to a network selected by an operator as managed one.

---

### **IMPORTANT**

**Besides a local network (finally) any other network is not automatically scanned without a decision of the system administrator.**

---

SNMP requests, both to newly discovered devices and to already included in the Database, are sent with a community according to information included in the [configuration of SNMP communities](#). A similar process for each discovered device as that one performed in the moment of its discovering is prepared every specified period of time. This period is one of attributes of a state group to which a given object belongs. Then all knowledge about the device configuration included in the Database is updated. This process is performed every hour by default. It may occur earlier if **dnmmsd** discovers any error in responses from a given device.

When a new discovered device is added, its all network interfaces and BGP peers (if it has them) are added to the Database. The device is also scanned for all active and permitted IP address of managed item groups. IP address of one of the device network interfaces is also added to ping objects (an IP address corresponding to a device name described as `sysName` is preferred). When information about a device is updated, its all network interfaces, BGP peers and managed items discovered using managed item groups are checked. Newly discovered interfaces, BGP peers and managed items are added, but these one which can't be found are marked as removed.

Beside periodic update of each monitored device configuration, checking of states of network interfaces, BGP peers, managed items and ping objects is performed more often. That period is specified as one of fields of a states group to which a given item belongs. Network interfaces and BGP peers are asked for an operation and administrative state. For managed items are checked suitable variables indicated by a user in the parent definition for a given item of managed item groups. Ping objects are monitored by sending five, short ICMP-ECHO packets to a given IP address with 1-second intervals. A state of a given item is calculated depending on received responses. For network interfaces and BGP peers, an UP (ESTABLISHED) state is treated as a correct state while the administrative state is UP too. If it's DOWN, the item state is always positive. For managed items, an answer, which values are treated as positive ones, depends on a definition of an origin managed item group for that managed items. Health of ping objects are measured as a percent of received responds for sent ICMP-ECHO packets. A positive situation is when this percent amounts 100%.

After the item state is calculated and it is different from that one just before the procedure, the change is

---

propagated to above (parent) levels in case the item is a network interface or BGP peer. Similar calculations are continued on higher levels of object parents until states are still changed. The following states are permissible:

- `Not managed` - an item is not managed;
- `Ok` - an item state is correct;
- `Minor fault` - an item state is not perfectly correct;
- `Major fault` - an item fault is considerable;
- `Critical` - an item is in a critical state;
- `Was minor fault` - an item state was not perfectly correct but it is better now;
- `Was major fault` - an item fault was considerable but it is in a better state now;
- `Was critical` - an item was in a critical state but it is in a better state now;
- `Unknown` - an item state is unknown;
- `Error` - an error occurred for a particular item (this state should last long);
- `Deleted` - an item was not found in a current device configuration.

A state of a given item is not modified and doesn't affect its higher level items (its parent or owner) as the flag `Is passive` of the item is set.

A log message is written to a particular table as a response for each change of network interface state, BGP peer, managed item state or ping object state.

For each item additional informing possibility about alarm situations exists. For each network interface, BGP peer and managed item being in `Critical` state a following script is run every 5 minutes: **`netinterface-alarm.sh`** for network interfaces, **`bgppeer-alarm.sh`** for BGP peers and **`mitem-alarm.sh`** for managed items. For ping object, when a percent of answers for it is less then 100%, the program **`ping-alarm.sh`** is run. It's run periodically every specified period of time until the state doesn't come to OK. The period is one of attributes of a ping object group to which the ping object belongs. The issue how to configure ping object alarms is described in [Network Management Map \(xdnmm\)](#).

## 9.8. Input parameters passed on `netinterface-alarm.sh` program

An external program is run for a network interface when it is in `Critical` state. The program receives

information, as its input parameters, about a given network interface in the following format:

- `alarm-on` or `alarm-off` - shows if an alarm (i.e. sound) for a given network interface is turned on;
- `test-on` or `test-off` - shows if it is a test or not;
- a network interface name;
- a network interface description - (alias);
- a number of the program calls since the last state change;
- a time which passed since the last state change;
- a network interface administrative state;
- a network interface operation state;
- a device name, that is an owner of the network interface;
- a calculated community of the network interface.

## 9.9. Input parameters passed on `bgppeer-alarm.sh` program

An external program is run for a BGP peer when it is in `Critical` state. The program receives information, as its input parameters, about a given BGP peer in the following format:

- `alarm-on` or `alarm-off` - shows if an alarm (i.e. sound) for a given BGP peer is turned on;
- `test-on` or `test-off` - shows if it is a test or not;
- a BGP peer description;
- a BGP peer IPaddress;
- a BGP peer AS number;
- a number of the program calls since the last state change;
- a time which passed since the last state change;
- a BGP peer administrative state;
- a BGP peer operation state;

- a device name, that is an owner of the BGP peer;
- a calculated community of the BGP peer.

## 9.10. Input parameters passed on mitem-alarm.sh program

An external program is run for a managed item when it is in `Critical` state. The program receives information, as its input parameters, about a given managed item in the following format:

- `alarm-on` or `alarm-off` - shows if an alarm (i.e. sound) for a given managed item is turned on;
- `test-on` or `test-off` - shows if it is a test or not;
- a managed item description;
- a number of the program calls since the last state change;
- a time which passed since the last state change;
- a device name, that is an owner of the managed item;
- a name of the source group of managed items;
- a calculated community of the managed item.

## 9.11. Input parameters passed on ping-alarm.sh program

An external program is run for a ping object when it is in `Critical` state. The program receives information, as its input parameters, about a given ping object in the following format:

- `alarm-on` or `alarm-off` - it shows if an audio alarm for the object is turn on;
- an object name or its IP address;
- IP address;
- a number of the program calls since its last OK state;
- a time which passed since its last OK state;
- a percent of received responses;

- a number of received responses;
- a number of sent requests;
- a name of ping object group which the object belongs to.

## 9.12. Related articles

[Network Management Map \(xdnmm\)](#)

[Excluded IP Address Configurator](#)

[SNMP Community Configurator](#)

---

# Chapter 10. Enhanced Data Collector (dedcd)

## 10.1. General

**dedcd** is **Enhanced Data Collector** and it is a part of **Network Manager**. It is a daemon process which works all the time the system is running. It collects suitable data of monitored devices by SNMP protocol. It receives information about collected data from [Service of Network Management Map \(dnmmsd\)](#).

## 10.2. Synopsis

**dedcd** can be run with the following options: `[-P,--pid-file filename]`  `[--background]`  `[-l,--log-facility log_facility]`  `[-L,--log-level log_level]`  `[-u,--run-as-user username]`  `[-f,--password-file filename]`  `[--out-queue-ttl seconds]`  `[--max-load4collect number]`  `[--max-sent-pdus number]`  `[-v,--version]`  `[-h,--help]`

## 10.3. Options

Table 10.1. dedcd options

Option name	Description
<code>-P,--pid-file filename</code>	Write PID to a specified file.
<code>--background</code>	Go to background after startup.
<code>-l,--log-facility log_facility</code>	Choose log facility: daemon   user   local0   ...   local7 (default: local6).
<code>-L,--log-level log_level</code>	Choose log level (on stderr and syslog) i.e. messages of selected level and more important levels will be logged: emerg   alert   crit   err   warning   notice   info   debug0   ...   debug2 (default: notice).
<code>-u,--run-as-user username</code>	Drop root privileges and run server as the specified user.
<code>-f,--password-file filename</code>	Specify a file (in \$DAVIDPRIVDIR) containing a username and a password to log in to the server (default: .edc.pwd).
<code>--out-queue-ttl seconds</code>	Specify a maximum TTL for outgoing messages (default: 300 seconds).
<code>--max-load4collect number</code>	Specify a maximum system load to suspend collections (default: 40.0).
<code>--max-sent-pdus number</code>	A maximum number of sending PDUs at the same time (default: 20).
<code>-v,--version</code>	Display version number on stderr and exit.
<code>-h,--help</code>	Display this help and exit.

## 10.4. Description

During its startup **dedcd** module tries to communicate with [dnmmsd](#) module from which it will be received information needed to run collections, and with **damsnmpdaud** module to which it will be sent collected data. When **dedcd** can't connected with any modules, it will try to connect with it every some period of time. It does the same if a connection is interrupted. In a case of a connection lack with [dnmmsd](#) module no collections are carried on.

An important property of **dedcd** is a fact, that it automatically reacts on all changes in **Network Information Database** managed by [dnmmsd](#) module. So, data from newly discovered devices and network interfaces will be automatically collected, and collections will be stopped for devices deleted form **Network Information Database** and i.e. network interfaces marked as deleted through [dnmmsd](#) module.

Almost all configured information concerning collected device parameters, a frequency of sending messages to them, a graph coloring etc. come from **Network Information Database** and they can be configured with a level of [Network Management Map](#) application.

Results of **dedcd** work are shown the best through David system Web interface.

## 10.5. Related articles

[Service of Network Management Map \(dnmmsd\)](#)

[Network Management Map Client\(dnmmsc\)](#)

[Network Management Map \(xdnmm\)](#)

**Operation Manager:** SNMP Data Analyser (damsnmpdaud)

---

# Chapter 11. Slow Query Executor (dsqed)

## 11.1. General

**dsqed** program is **Slow Query Executor** and it's a part of **Network Manager**. It is a daemon process which works all the time the system is running.

## 11.2. Synopsis

**dsqed** can be run with the following options: `[-P,--pid-file filename]` `[-l,--log-facility log_facility]` `[-L,--log-level log_level]` `[-u,--run-as-user username]`  `[--background]` `[-v,--version]` `[-h,--help]`

## 11.3. Options

Table 11.1. dsqed options

Option name	Description
<code>-P,--pid-file filename</code>	Write PID to a specified file.
<code>-l,--log-facility log_facility</code>	Choose log facility: daemon   user   local0   ...   local7 (default: local6).
<code>-L,--log-level log_level</code>	Choose log level (on stderr and syslog) i.e. messages of selected level. and more important levels will be logged: emerg   alert   crit   err   warning   notice   info   debug0   ...   debug2 (default: notice).
<code>-u,--run-as-user username</code>	Drop root privileges and run server as the specified user.
<code>--background</code>	Go to background after startup.
<code>-v,--version</code>	Display version number on stderr and exit.
<code>-h,--help</code>	Display this help and exit.

## 11.4. Description

**dsqed** program executes slow SQL queries, that delete data from SQL table. The queries are created by the other modules of **David system**. It allows modules to work all the time without breaks, that can execute slow SQL queries. And **dsqed** program executes all prepared queries one by one.

If the program doesn't have any queries to execute, it optimizes the SQL tables, that queries deleted more than a definite number of records. It is 50000 records by default.

## 11.5. Related articles



[Network Management Map \(xdnmm\)](#)

[Service of Network Management Map \(dnmmsd\)](#)

[Enhanced Data Collector \(dedcd\)](#)

---

# Chapter 12. Network Management Map (xdnmm)

## 12.1. General

**xdnmm** application is **Network Management Map (xdnmm)** and it is a part of **Network Manager**. It's a graphic client of [dnmmsd](#) daemon that services **Network Management Map**, i.e. it polls devices in managed networks using SNMP protocol and ICMP (ping). The client is the comfortable interface and it delivers a visualization and makes commands on objects of **Network Information Database** that is wholly managed by [dnmmsd](#).

## 12.2. Synopsis

**xdnmm** can be run with the following options: [[-l,--log-facility log\\_facility](#)] [[-L,--log-level log\\_level](#)] [[-v,--version](#)] [[-h,--help](#)]

## 12.3. Options

Table 12.1. xdnmm options


Option name	Description
<a href="#">-l,--log-facility log_facility</a>	Choose log facility: daemon   user   local0   ...   local7 (default: local6).
<a href="#">-L,--log-level log_level</a>	Choose log level (on stderr and syslog) i.e. messages of selected level and more important levels will be logged: emerg   alert   crit   err   warning   notice   info   debug0   ...   debug2 (default: warning).
<a href="#">-v,--version</a>	Display version number on stderr and exit.
<a href="#">-h,--help</a>	Display this help and exit.

## 12.4. Description

### 12.4.1. Starting up and terminating the application


**xdnmm** reads its configuration parameters from `.xdescrc` file during its startup. The parameters concern an appearance of the program and other working parameters. The application expects to find its configuration file in a directory which name is kept in the environmental variable **\$DAVIDPRIVDIR**. When the file doesn't exist, the application will begin its work with its default settings.

## 12.4.2. Main window work



The application is a graphic client of [dnmmsd](#) server and in this connection it has have complete functionality after its connection process with the server. The connection will be realized when the application user identifies on the server passing his identifier and his password. After the successfully authentication, data of **Network Information Database** accessed through the server, are loaded. This process usually takes a little time. A progress of this process is visualized by the application. **xdnmm** has the complete functionality after ending of this process.

## Network Management Map (xdnmm)








A main view of the application can be split into any number of horizontal and vertical panels. Each panel can include other object. Only one panel is always active. It is surrounded by a green frame.

At the bottom of the application view is the status bar. Two counters: incoming and outgoing messages are placed from the left side of the status bar.

There are also the buttons described below:

**Table 12.2. xdnmm - the status bar buttons**

Button	Description
	It fulfills some functions. Pressing the button in the state like that causes connection with the server when the application isn't connected with it yet, otherwise when you press the button, the application will be in the active mode to read only. It changes a button picture on the button below.
	When you press the button in this state, the application will be in the mode making possible modification of the Database items after successfully authentication process (you don't need to login as the same user). The button picture again comes back to the initial state.


Button	Description
	It allows you to connect with the server or login to the server again (the application is in the active mode).
	It shows if the application is locked.
	It shows if the application is unlocked.

Before the button that shows if the application is locked or not, three fields are placed. First and second field describes a logged in user's identifier and his level of rights. After them, there is the application identifier which is assigned its by the server. The last item is an indicator of a current connection status of the application with the server.

### 12.4.2.1. Main window buttons




On the toolbar are placed the buttons that allow you to control the application work. The first button from the left agree with option from `File` menu.

**Table 12.3. xdnmm - the File menu buttons**

Button	Description
	It allows you to lock access to the application. Then if you press any button of the keyboard or the mouse, or move the mouse, <code>Authorization</code> dialog will appear. In the dialog you should write a username and a password to unlock access to the application and login again to the server (you don't need to login as the same user).













In `File` menu also are options which aren't placed on the toolbar.

**Table 12.4. xdnmm - File menu buttons which aren't placed on the toolbar**

Button	Description
 - Connect	It allows you to connect with <a href="#">dnmmsd</a> server to login.
	It lets you disconnect with the server (to logout).
	It lets you exit the application.

Next buttons agree with `Edit` menu. There are the buttons to edition of different objects and after pressing them, non-modal edition dialogs appear. In each case you can edit unlimited number of objects at the same time by suitable selecting of them.

**Table 12.5. xdnmm - the Edit menu buttons**

Button	Description
	It opens the window allowing to edit styles.
	It opens the window allowing to edit state groups.
	It opens the window allowing to edit communities.
	It opens the window allowing to edit the collection groups.
	It opens the window allowing to edit managed items groups.
	It opens the dialog allowing to edit network interfaces of the current monitoring device. In this case you can't get a list of current available network interfaces in the Database because it doesn't exist.
	It opens the dialog, that allows you to edit BGP peers of the current monitoring device. In this case windows with current BGP peers in the Database don't exist. The device must be a <code>router</code> type.
	It opens the dialog, that allows you to edit managed items of the current monitoring device. In this case a dialog with all managed items doesn't exist.
	It lets you open a window to edit objects. You can choose objects to edition when you mark them on a current presented map. In this case you can also edit many windows at the same time.
	It opens a window that allows you to edit ping objects.
	It opens a window that lets you edit ping object group.
	It lets you delete selected item.

In Edit menu another options are placed which don't show on the toolbar.

**Table 12.6. xdnmm - Edit menu options which aren't placed on the toolbar**














Option	Description
Reset to OK state	It lets you change an item state on OK state. If an item is an object and includes others sub-objects, their state will be changed too with the exception of a state marked as <code>Not managed</code> or <code>Delete</code> .
Manage	It lets you to set a state of chosen items on OK state and begin a management of this items. If an item is an object of <code>Network</code> type, the process of its discovering (scan procedure) will be begun. If an object is <code>computer</code> or <code>router</code> type, its all network interfaces and some current BGP peers will be managed (i.e. their state on this device will be monitored).

## Network Management Map (xdnmm)





Option	Description
Manage but don't discover	It complies with objects of <code>Network</code> type. Then a propagation service of item states will be run. Item states have an influence on these items but a scan procedure of a network won't be run. Non-scanned networks have a blue color.
Don't manage	It sets a selected object state on <code>Not managed</code> value.
Move up	It lets you move up selected objects to a map being higher in a map hierarchy, i.e. to an object including a current presented object.
Discover (poll) node	It allows you to discover a given device or poll it again if it is placed in the Database. In this way you can update its configuration.
Save positions of ping panels	Save positions and sizes all panes, that show ping objects.

There are some buttons on the toolbar that agree with `View` menu.

**Table 12.7. xdnmm - View menu buttons**

Button	Description
	It lets you find an object being on the top of a hierarchy, i.e. <code>Root Map</code> object.
	It allows you to enter inside of an object selected as a home object. Currently it always is <code>Root Map</code> object.
	It lets you enter an object standing higher about one step in a hierarchy, i.e. a parent of a current presented object.
	It lets you look at an object inside. It's synonymous with double clicking on an object.
	It allows you to look at a selected item ( <code>computer</code> or <code>router</code> type) using <a href="#">Network Nodes Viewer (xdnvv)</a> , if you find a suitable control panel for it.
	It lets you do a similar operation like before but a device name or an IP device you can pass as an argument of a command. In this connection a given device hasn't to exist in the Database.
	It opens a dialog presenting a list of logged in users on <a href="#">dnmmsd</a> server.
	It lets you receive a list of all current defined styles in the Database.
	It lets you receive a list of all current defined state groups.
	It lets you receive a list of all current defined communities.
	It lets you receive a list of all current defined the collection groups in the Database.
	It lets you receive a list of all current defined managed item groups.
	It lets you edit a list of all defined layers in the Database. The layer unctinality isn't currently used in <b>Network Management Map</b> .

## Network Management Map (xdnmm)

Button	Description
	It opens a dialog that presents ping objects.
	It shows you a list of current defined ping object groups in the Database.
	It lets you look at a waiting room in which new-discovering objects wait for adding them to a selected item (map). In this case you should select objects from the waiting room using the mouse and move them to a current presented object (map).
	It lets you configure working parameters of the application.

In View menu other options are additionally placed which don't show on the toolbar.

**Table 12.8. xdnmm - the View menu buttons, that aren't placed on the toolbar**




Button	Description
Show tool bar	Show or hide the tool bar.
Show status bar	Show or hide the status bar.
Show deleted elements	Show or hide elements marking as deleted.
Show not managed elements	Show or hide elements, that are in Not managed state.
Split view horizontally	It splits horizontally an active panel into two separated panels.
Split view vertically	It splits verically an active panel into two separated panels.
Close view	Close an active panel.

The last three options agree with David system menu and let you run the David system applications:

**Table 12.9. xdnmm - the David system menu buttons**




## Network Management Map (xdnmm)

Button	Description
	Events Service Configurator (xdesc);
	Graphic Notifications Presenter (xdgnp);
	<a href="#">Network Node Views Editor (xdnve)</a> .

Through Help menu you can find out the application version and its creation time.

### 12.4.2.2. Maps and objects exploration




A main view of the application is inside of a presented object. In the Database at last one object always exists. It's a localization which is named `Root Map` and it stands on the top of an object hierarchy. Some objects can include other objects. In this way you can create hierarchy structure of Database objects. You can see the object inside in very simple way, by double clicking on itself. The application allows to add different types of objects:

- objects of type `Location` can include some, other objects;
- objects of type `Device` are agreed with a physical network devices;
- objects of type `Network` are agreed with discovered networks – added automatically;
- objects of type `Link` are connections between two objects of below types on the same map.




When the browsed object is agree with real device (a type of `Device`), its inside shows a little information about the device and a list of network interfaces, BGP peers and managed items.

Network Management Map - ku

File Edit View David system Help


Property	Value
Image	
Type	Device
Name	
Device type	Computer
Vendor	Unknown
Model	Unknown
System uptime	39 days 12:53:58
System name	
System description	SunOS Generic_106541-44 sun4u
System OID	1.3.6.1.4.1. 0x4C
System services (OSI layers)	(3) network layer (4) transport layer (7) application layer
Device IP	.192.
Community	

Group	Items
Bgp peers	No Bgp peers
CPU usage	1 item (click to explore)
Dependencies	No dependencies
Disks	10 items (click to explore)
Icmp input packets	1 item (click to explore)
Icmp input packets - h	1 item (click to explore)
Icmp output packets	1 item (click to explore)
Icmp output packets - h	1 item (click to explore)
IO requests	1 item (click to explore)
Load	3 items (click to explore)
Network interfaces	3 network interfaces (click to explore)
Udp datagrams	1 item (click to explore)
Udp datagrams - h	1 item (click to explore)



 Msg in: 5582  
 Msg out: 4278
 

 Last input:  
 2008/11/28 13:56:

A type of Device includes a few subtypes: Router, Computer, Ethernet switch, UPS, etc.

Clicking on a line of the list describing network interfaces or BGP peers opens their detailed list.






Clicking on a list describing one of managed item groups opens their detailed list. A view of the managed item is specific for a given group and it depends on its define.



The options described below allows you to move between hierarchical maps of objects.

**Table 12.10. xdnmm - hierarchical maps of objects buttons**

Button	Descriptions
	It lets you see an object which is a parent of a current presented one.
	It lets you see an object on the top of whole hierarchy.
	It gives you the same effect as below but its work will be changed in the future and it will point at a presented object from which <b>xdnmm</b> application default begins its work after its connecting with <a href="#">dnmmsd</a> server.

## 12.5. A configuration of the Database items


You can make a configuration of **Network Information Database** items using un-modal windows. Some types of items have got additional windows presenting a list of all available items of a given type in the Database.

Each of edit windows has from the left side two or more buttons that allow you to move between panels within a edit window. Beside a specific panel for a given item, at last one more panel exists and it describes [access rights](#) to an item or a whole list of items. All edit windows with an exception of two have four following buttons:

- `Apply and Close` - confirms changes and closes a window;
- `Apply` - confirms changes without closing a window;
- `Close` - closes a window;
- `Add as new` - adds a new item on the basis of current specified item parameters.


There isn't the last `Add as new` button in edit windows for network interfaces and BGP peers and managed items. Thereby you can't add this items to the Database because the system adds and backups the items itself on the basis of a managed device configuration.



### 12.5.1. Styles configuration




Styles are items of state groups. The states groups can accept the Database items as i.e.: network interfaces and objects. Each style includes an unique style identifier to others styles and it can include a name. It has two properties signified as `OFF color` and `ON color`. That colors mean states on/off and they create an effect of fleshing colors of an item. You can do the effect setting a timer value greater then zero and pressing `Flash` option. Otherwise a continuous color will be used which is signed as `ON color`.

### 12.5.1.1. A list of available styles




A list of styles presents styles sorted according to their names. There are properties of particular items in the columns. Selected items of a list can be edit in the [Style](#) window. You can open  it pressing the button below the item list or choosing the window from the main view of the application. You can choose more then one selected item. The right button  below the item list allows you to delete selected items of the item list.



## 12.5.2. A configuration of state groups



State groups specify a work of the Database items such as: network interfaces, BGP peers, objects and ping objects. Each of the items includes a field describing to which a state group a given item belongs. Each state group includes an unique identifier with relation to other state group and it can include a name. It also includes a list of styles that agree with particular states beginning with `Not managed` and finishing on `Passive`. A state group also have three fields defining levels of particular state items. All possible values belong to a rang  $<0;1>$ . An item state will be defined as `OK`, if a counting value of an item is below `Minor level`. Otherwise, if an item value is below `Major level`, an item state will be described as `Minor fault`. Otherwise, if an item value is below `Critical level`, an item state will be described as `Major fault`. Otherwise an item state will be `Critical`. An item value that presents physical device (`computer` or `router`) is counted on the basis of its included items such as: network interfaces, BGP peers and managed items. In other cases states of item children influence on an item state (i.e. `location`). In this way states of children propagate on higher levels of a map hierarchy through their parents. Additionally on states of items influence item states from which the items are depended on (`Dependences`). The last two fields of a state group are `Update interval` and `Check interval`. The first one describes about what period of time (in seconds) a configuration of monitored devices will be actualized by SNMP protocol and second one - about what period of time an item state will be checked. In a natural way the first field is used for physical devices and second one for network interfaces, BGP peers, managed items and ping objects.


### 12.5.2.1. A list of available state groups



A list of state groups presents state groups sorted according to their names. In the columns, properties of particular items are showed. Selected items of a list can modified in the [State Groups](#) window. You can open the window pressing a left button  below an item list, besides its opening in the main view of the application. There are more then one selected item. The right button  below an item list allows you to delete selected items from a list.

### 12.5.3. Communities configuration





Community it is an element, that includes a string and a kind of the operation, that can be done with it. The operations are done during work on two Community elements. As a result of the operation is a string. Kinds of operations are presented in the table below:

**Table 12.11. Meaning of Operation field in Community window**

Value	Description
Append	It sticks a string of one Community onto second one and use ' : ' mark as a separator.
Replace	It replaces a current string with a new one from the next Community.
Don't inherit	This Community is ignored during a string is calculated for children (i.e.: network interfaces).
Cut	It cuts out a string from a string inherited from its parent.

Name field allows you to write an item name, and then it is visible as its identifier, when you use an item.

Community items are used to control stream of information in many places of the system. They allow you to make a decision, who can be informed about any event or allow you to decide, that make any action or not, etc.

Community items can be set for such objects as: network interfaces, BGP peers, managed items, objects, ping objects.

A result string equivalent to a given object or ping object is equal a string of `Community` field, and `Community` item which is set for it. Calculating of a result string for network interfaces, BGP peers and managed items consists of two steps. First a string for a device, i.e. object which has a given item, is calculated, and then its own `Community` item is taken into consider. During the operations on these two `Communities` items, a sequence of items and values of their `Operation` fields figures much.

You have not to attribute `Community` items to any object. So, the result string can be empty for a given object.


### 12.5.3.1. An example of using of `Community` items

The example shows a work result of two `Communities` for a network interface (i.e. `so-1/0/1`) for a given device (i.e. `juniper-gw`). The device `juniper-gw` has `Community` with a string `a:b:c`. The network interface `so-1/0/1` has `Community` with a string `c:d`. The work results of these two `Communities` are presented in the table below:

**Table 12.12. The work results of two `Communities` depending on `Operation` field**

	<b>juniper-gw: a:b:c + append</b>	<b>juniper-gw: a:b:c + replace</b>	<b>juniper-gw: a:b:c + don't inherit</b>	<b>juniper-gw: a:b:c + cut</b>
so-1/0/1: c:d + append	a:b:c:d	a:b:c:d	c:d	a:b:c:d
so-1/0/1: c:d + replace	c:d	c:d	c:d	c:d
so-1/0/1: c:d + don't inherit	c:d	c:d	c:d	c:d
so-1/0/1: c:d + cut	d	d	c:d	d

### 12.5.3.2. A list of available communities




The list presents `communities` sorted into their names. Features characterizing particular items are shown in the columns. Selected items of the list can be edited in [Community](#) dialog. There are two buttons below the list:

**Table 12.13. Communities dialog - description of the buttons**

Button	Decription
	It opens <code>Community</code> dialog which also can be run from the main view of the application.
	It deletes selected items of the list. It can be more then one item.

## 12.5.4. Collection groups configuration



A collection group is a group of SNMP variables collecting same work parameters of a device. The variables have properties allowing to collect them and defining a method of their visualization. Each variable defines one work parameter of a device.

Collection on the base of their parameters are automatically allocated to devices and network interfaces. When we added to the system managed item groups, meaning of collection groups was declined. Now, they are defining only collecting of traffic of network interfaces, so their another functions wear thin. Managed item groups characterize more general and flexible approach. For that's sake, we suggest, that defined groups won't be modified.

Collection group specific tab presents the particular features of collection groups. Name field is a text describing a given group and its identifier which is used in other parts of **David system**. Type describes a collection type. The following table characterizes them shortly:


**Table 12.14. Types of the collection groups**

Type	Description
Net interface	The collection is destined for network interfaces not-supporting 64-bit counters.
Net interface (High Capacity Counters)	The collection is destined for network interfaces supporting 64-bit counters.
Object	The collection is destined for an object.

## Network Management Map (xdnmm)

Type	Description
External	The collection allows to visualization external data. No real data are collected for the collection, but if you define the collection, you can browse the data through the web application <a href="#">Collection Browser</a> . The data are saved in the Database by a script run by UNIX CRON service.
Aggregated	The special collection is destined for pooling of collections which are collected for network interfaces. Only network interfaces, assigned to a given collection, provide data to it.

SQL DB Table (external) field is important for an External type collection. It includes SQL table name from which [Collection Browser](#) will be read data during a graph drawing. Background color field helps you to specify a background color for graphs of collected data. Polling interval field shows an interval, in seconds, of which another sample is collected. Vendor OID and SNMP version fields let you specify criterions, and on the base of them, the collection will be assigned to an item of the given device. Vendor OID field includes OID which is compared to OID variable, finding on a given device. The field is treated as the beginning of that OID. The vendor is omitted as a selection parameter if that field is empty. SNMP version field shows a minimum version of SNMP protocol, that a device has to provide. If these two fields satisfy the conditions, a collection is assigned to a device or its network interface.



Variables tab presents a list of SNMP variables defined for a given group. The view is split into two parts: the top one presents a list of variables, and the bottom one allows to edit particular items of the list. There are four buttons below, that allows to add a new item to the list, delete an existed one and change an order of the item list.

Selecting a list item causes showing its fields into the edit fields, so any change you make there modifies the selected list item. Name field shows a variable name. It is visible during drawing of a graph and it explains meaning of a variable. Column name field - it is a column name in SQL table created automatically in the Database, where variable values are saved. OID field specifies OID, that a variable is

in evidence in SNMP protocol. In a case of collections for network interfaces, a number `ifIndex` of a given network interface is added to that field value at the end. `Color` field defines a variable color, that it is drawn on a graph during data visualization. `Style` field tell us, how the variable values will be treated and if it will be drawn. The following table presents values of `Style` field and their meaning:

**Table 12.15. Values of Style field for variables of collection group**

Value	Description
Do not draw	A variable is not draw on a graph.
Draw value	The variable values can be changed in any line, i.e. they can be increasing or decreasing.
Draw increase of value	The variable values can only increase until it reaches a maximum value and starts increasing again from zero. It is a characteristic feature of counters.

Extended `style` field shows, in which way a variable will be drawn. It can have three values, but `Bar` value is not taken account. `Line` value lets the variable draw as a line, while `Filled` value lets a graph fill at the bottom. Enhanced `style` field can have four values: `Min`, `Max`, `Min & Max` and `Avg`. The field has historical meaning, because `Avg` value is always used. `Factor` field is a number on which variable values are multiplied by during its drawing and further processing. Its value also tell us how many times you should multiply a variable value, that its quantity was expressed in units specified in `Unit` field. It can have the following values:

- bits/sec;
- kbits/sec;
- Mbits/sec;
- Gbits/sec;
- Bytes/sec;
- kBytes/sec;
- MBytes/sec;
- GBytes/sec;
- Pkts/sec;
- kPkts/sec;
- MPkts/sec;


- GPkts/sec;
- Other.

Octet length field, if it is greater than 0, shows how many bytes (octets) a given variable has (i.e. if it is a value of 32 or 64 bits). The field `Accounting type` shows if the variable is accounted or not and, if it is, how its values should be treated. The field can get following values:

**Table 12.16. Values of the field Accounting type for variables of collection group**



Value	Description
None	The variable is not accounted.
Input octets	Values of the variable are accounted as input octets (bytes).
Output octets	Values of the variable are accounted as output octets (bytes).
Input packets	Values of the variable are accounted as input packets.
Output packets	Values of the variable are accounted as output packets.

### 12.5.4.1. A list of available collection groups




The list presents the collection groups, that are sorted into their names. Features characterized particular items are shown in the columns. Selected items of the list can be edited in [Collect group](#) dialog. There are two buttons at the bottom of the list.

**Table 12.17. A description of the Collect groups buttons**

Button	Description
	It opens Collect group dialog, that you can also run from a main view of the application.
	It let you delete selected items of the list. It can be more then one selected item.

## 12.5.5. Managed item groups configuration

Managed item groups are definitions, that interpret particular items of tables which are in devices MIB and accessible through SNMP protocol. The definition allows to describe a few ways of data interpretation. A part of data from a given table can be collected, and another part of data can be monitored, while another one can be only gathered during a standard procedure of data update of a given device. The device is searched at an angle data specified in a definition of the group, during the update procedure. The finding data, that match the group definition, become the managed items. They can represent any work aspects of a device: serviced protocols (BGP, ISIS, OSPF, MPLS, VPN etc.), physical device elements (ports, interfaces, power supplies, fans, procesors etc.) and other entities accessible by SNMP protocol (i.e.: filters of packets).



Parameter	Value
ID	123
Name	CPU
Description	Cisco CPU load
Activated	No
Background color	
Polling interval	288
Array OID	1.3.6.1.4.1.9.2.1
Vendor number	9
Scan MIB as table	No
Add zero to OIDs during SNMP-GET	No
Valid for logical devices	No
IP address regular expression	
Excluded IP address regular expression	
Valid for subinterfaces if linked to netinterfaces	No
Alarm allowed for its managed items	No
Accounting for its managed items	No
ID string	2007/09/12 11:45

Managed item group specific tab shows particular features of the managed item groups. Name field includes a short name of the group. It is visible during browsing of a collection or a content of a given device, so it should show clearly which aspect of device working it concerns. Description field allows to describe a content of the table which is scanned using the group. Activated field shows, if the group is taken into consideration during the data update. Background color field describes a background color of drawn graphs for data, collected on the strength of the group. Polling interval field shows an interval, in seconds, of which another collected data of the group are collected. Array OID field includes an OID of the MIB table which is scanned to search managed items. Vendor number field describes an identifier of device vendor, that will be scanned for the group. If a



value of `Vendor number` field has 0, the group is looked for on devices of all vendors. `Scan MIB as table` field shows, if a group definition relates to a table in MIB database or to its scalar values. In other words, scanning of MIB database is done according to searching of rows of a given table or ordinary scalar values. `Add zero to OIDs during SNMP-GET` field allows to go around errors of SNMP implementation on some devices. The error shows rather seldom (some SNMP agents on measures SNMP to UPS of APC company), the problem is, that a request `SNMP-GETNEXT` for some MIB elements gives back the next element, which answers in error on a direct request `SNMP-GET`. If you want to get a correct answer, you should add '0' to its identifier. So, `Add zero to OIDs during SNMP-GET` field almost has always No value. `Valid for logical devices` field describes, if logical devices (logical routers of Juniper company) will be searched at an angle the group or not. Because some MIB table are the same both physical devices and logical devices configured on them, duplicating data is no use. `IP address regular expression` field allows to limit searching of the group for devices, that are polled through a given set of IP addresses. The empty field shows, that IP address doesn't decide about searching of the group on a device. `Excluded IP address regular expression` field lets you limit searching of groups for device, that are polled through excluding a given set of IP addresses. The empty field shows, that IP address doesn't influence on decision to search group on a device. `Valid for subinterfaces if linked to netinterfaces` field shows, that managed items, finding on a scanned device and connected with its network interfaces, will be ignored, if a connected interface is a subinterface. There are some situations when the same data are replayed for all elements corresponding with subinterfaces of the same network interface. In this case monitoring of an element is sufficient, that is connected with a main network interface. `Alarm allowed for its managed items` field allows to describe, if for managed items, discovered by the group, will be run scripts alerting about CRITICAL state. `Accounting for its managed items` field shows, if given variables are accounted or not. If they are, the variables, that a value of `Accounting` field is different from None, are accounted. `ID string` field includes a string identifying a given managed item group. For convenience, the field includes a date of creation of a given group. The field is only important during actualization of **Network Manager** product, because new, identified groups are added on the base of this field.

## Network Management Map (xdnmm)

Name	Index	Type	Enum properties	Bit mask properties
5 sec. load		56.0	Integer	
1 min. load		57.0	Integer	
5 min. load		58.0	Integer	

Parameter	Value
Name	5 min. load
Index	58.0
Type	Integer
Enum properties	
Bit mask properties	
Static	No
Description	No
Editable	No
Collected	Yes
Managed	No
Saved	No
Save trigger	No
In comparisons	No
Inside responses	No
Unit	Other
Column name	min5
Style	Line
Factor to unit	1.0000000000000000
Factor	1.0000000000000000
Color	
Octet length	0
Maximum value	0.0000000000000000
Minimum range	0.0000000000000000
Maximum range	0.0000000000000000
Accounting type	None
Exclusion string	

Entries tab presents a list of searched items of a given group during scanning of a device. If MIB table is scanned, each entry is agreed with a single column of the table. If scalar values are scanned, the connections between entries can be default, free. The panel is split into two parts: the top one shows a list of entries, and the bottom one lets to edit elements of the list. There are four buttons below the list, that allow to add a new element to the list, delete an existed item and change a sequence of the list.


Selecting of the list item concerns, that its fields appear on edited fields and any change changes the list item. Name field includes an item name (a column). Index field specifies a column index of MIB table,

that the entry concerns. Indexes of all entries in a given group have to be different from themselves. An index lower than zero shows, that the item isn't taken from MIB table but is defined by a user. Type field describes type of values and shows in which way a value of MIB object can be interpreted. The below table presents values of Type field and their meaning:

**Table 12.18. Values of Type field for entries of managed item group**


Value	Description
String	The field is a string.
Integer	The field is a signed integer.
Enumeration	The field includes a set of the enumeration values.
Administration state	The same meaning as Enumeration field, but additionally with a tip about meaning of the field.
Operational state	The same meaning as Enumeration field, but additionally with a tip about meaning of the field.
Unsigned integer	The field is an unsigned integer.
Value	The field includes a real number.
Counter	The field includes a counter.
Speed	The field includes a number in bits/sec.
Bool	The field includes a bool number.
Date and time	The field includes date and time.
Bit list	The field is interpreted as a list of bits (i.e. hexadecimal string), where positions of bits '1' are printed out..
Other	The field includes other type of data and it is treated as a string.

Enum properties field includes a list of enumerated values, that an object of the MIB table can have. A set of the enumerated values isn't ignored only then Type field is set an Enumeration, Administration state or Operational state value. If you want to edit the list, you should click Enum properties field. The appeared dialog lets you edit particular items of the list of enumerated values.



Enumeration properties window lets you edit a list of enumerated values. Each value must be unique. Each entry corresponding to an enumerated value has Description field, that is a texted description of the value and it shows, that it is a positive or negative value. Color field specifies a color, that a value is drawn.

The field Bit mask properties of Entries tab includes a list of the bit masks, that can include values of MIB table object. Values of the field are taken into consideration, when they exist, regardless of a value of Type field. When you want to edit the list, you should click on Bit mask properties field. The open dialog lets you edit particular elements of the bit mask list.



Bit mask properties dialog lets edit a list of the bit masks. Each entry corresponding with bit mask in the form of hexadecimal includes Description field which is text description of a bit mask. The field Is always visible describes, if a value of a given mask is shown always or only then,

when it shows.

Static field of `Entries` tab lets describe, if values of the MIB object are dynamic, i.e. they are taken from MIB by SNMP protocol, or if they are edited by a user. `Description` field describes, if values of the MIB object are treated as a description of the managed item. `Editable` field shows, if a value can be edited by a user, while `Collected` field shows, if values of the MIB object are collected by [dedcd](#). `Managed` field shows, if the MIB object is monitored, in other words, SNMP requests concerning its value periodically are send by [dnmmsd](#). `Saved` field describes if monitored requests would be saved, when values are changed. In other way values are only updated, their changes are ignored and aren't logged to logs. `Save trigger` field shows if the MIB object change involves writting down whole managed item to log. In `comparisons` field shows, if a given MIB object is taken into consideration during comparison of two managed items. If one field has `TRUE` value, only the values of the MIB objects mean during comparison of two managed items. In other coincidence, item indexes are compared with. Manged item comparison is taken during the update procedure of a device. Then, the managed items are updated, new one are added and the not-existed one are deleted. `Inside responses` field shows, if values of the MIB object are included in responses to requests of [dnmmc](#). `Unit` field specifies units, in which the MIB object values are expressed. It is important i.e.: during drawing of graphs. The field can have the following values:

**Table 12.19. The Unit field values for entries of the managed item group**

Value	Description
bits/sec	It shows a number of bits in second.
Pkts/sec	It shows a number of packets in second.
sec.	It shows time.
Other	It shows other units.

`Column name` field is important if the column values are collected. It specifies a column name in SQL table, when data are gathered. `Style` field shows, how the MIB object values will be drawn. The below table shows possible values:

**Table 12.20. Style field values for entries of the managed item group**

Value	Description
None	No values are drawn.
Line	A linear graph.
Filled	A filled graph.
Bar	Bars.

`Factor to unit` field shows a number which multiplied by a value of the column gives an amount

expressed in units that `Unit` field shows. `Factor` field shows a next multiplier. It is used during sending the data to **Operation Manager** product. `Color` field specifies a color which the column values are drawn. `Octet length` field, if it is greater than 0, shows how many bytes (octets) a given variable has (i.e. when it is a value of 32 or 64 bits). `Maximum value` field lets you set a maximum value of a given variable. `Minimum range` and `Maximum range` fields let you set a range of acceptable values for this variable. Values outside the range generate alarm situations. The field `Accounting type` shows if the column is accounted or not and, if it is, how its values should be treated. The field can have the following values:

**Table 12.21. Values of the field Accounting type for entries of managed item group**

<b>Value</b>	<b>Description</b>
None	The column is not accounted.
Input octets	Values of the column are accounted as input octets (bytes).
Output octets	Values of the column are accounted as output octets (bytes).
Input packets	Values of the column are accounted as input packets.
Output packets	Values of the column are accounted as output packets.

`Exclusion string` field - if it is not empty, it shows what kind of variable string excluded whole managed item from monitoring.



Indexes tab shows elements of indexes which managed items have and they are a result a definition of the group. The tab is empty in mainly cases. You can use the tab, when you want to search MIB table and choose its a few rows. Indexes tab defines an item selection on the base of index values. It includes a list of a part of the index until the part being a filter. Each of the parts has a few properties, that define it.

The panel is split into two parts: the top one presents a list of indexes, and the bottom one allows to edit particular items of the list. There are four buttons below, that allows to add a new item to the list, delete an existed one and change an order of the item list.

Selecting of a list item causes appearing its fields into the edit fields, so change of the list item is made by any change.

Name field lets you remember meaning of the item. Fixed length field show if the index part has fixed length, or not. If it has fixed length, Length field allows to pass the size. If Index field is specified, values of other fields are ignored, because both length and value can be set using Index field. A value of Index field is a filter of managed items. Only the managed items will be accepted, that an adequate index part is equal in Index field value. If the field is empty and in Fixed length field is selected No, a length of the index part is read from a next number included in index of the managed item.

Parameter	Value
Valid	No
Source type	Value
Source index	-1
Source start index	-1
Source index length	0
Destination type	Value
Destination managed item group	<null>
Destination index	-1
Destination start index	-1
Destination index length	0

Link tab allows to specify requirements on which a result managed item connects with other managed item or network interface. Valid field shows if a link is important or not. If not, another fields of the tab are ignored and no connection is created. Other fields are split into two groups. The first one concerns a source, i.e. processing, managed item, and the second one concerns an aim of connection. Source type field shows if an index of processing managed item is selected to search a connection or its value. If Value value is selected, Source index field includes a column index of MIB table, where the value is included. If a value of Source index field is Index, an index part of processing managed item is selected to search a connection. Then Source start index field includes an index of OID element, that is an item index while Source index length includes a length of a index part of the item, that will be used to comparison.

Analogical meaning have fields concerning a searched aim of the link. Destination type field can have one of three values:

**Table 12.22. Values of Destination type field for Link tab of managed item group**


Value	Description
IfIndeks	A network interface is a searched item about adequate value of ifIndex field.
Indeks	A managed item is a searched item about adequate column value with Destination index index of MIB table.
Value	A managed item is a searched item about adequate part of index, that begins on



Value	Description
	Destination start index position and has a length Destination index length.

Destination managed item group field show a destination group of the connection, if a value of Destination type field is Index or Value.

### 12.5.5.1. A list of accesible managed item groups



The list presents managed item groups sorted according to their names. Features characterized particular items are shown in columns. Selected items of the list can be edited in [Managed item group](#) dialog. There are two buttons below the list.


**Table 12.23. The buttons of Managed item groups dialog**

Button	Description
	It opens Managed item group dialog, that also can be opened in the main view of the application.
	It allows to delete selected items of the list. It can be selected more than one item.

## 12.5.6. Layers configuration

The functionality is currently inaccessible.

### 12.5.6.1. A list of available layers



A list of accessible layers presents layers sorted according to their unique identifiers. In the columns properties of particular items are showed. There are a layer type and regular expression described a layer. Because the layer functionality isn't used currently, we finish its description.

### 12.5.7. Network interfaces configuration

Network interfaces always belong to physical devices discovered by [dnmmsd](#) server. They represent both physical and logical network interfaces that are presented at monitored devices. They have many features and properties resulting from both their equivalents on physical devices and David system functionality.


Parameter	Value
ID	80
ifIndex	36
Description	BRI -Physical
Alias	Centrala
Type	isdns
Admin status	Up
Oper status	Down
Update alias	Yes
Collect	No
Update coll. avail.	Yes
Update speed	Yes
Draw utilization	Yes
Collect group	<null>
Speed (Bits/sec)	144000
High speed (Mbits/sec)	0
Main interface	myself

Specific tab includes fields, that are characteristic for a network interface. The fields `ifIndex`, `Description` and `Alias` are accessible by SNMP protocol and they characterize an interface (`ifIndex` is an interface index in MIB of a device). `Alias` field can be set by a system user permanently. The field shouldn't be written at the next reading of device configuration, and in this case you should set `Update alias` option as `No`. `Type` field describes an interface type and `Admin status` and `Oper status` - a current operation and administration state (i.e. UP, DOWN, UNKNOWN). `Collect` field shows, if the interface is collected. A collection name is showed by `Collect group`. If `Update coll. avail.` field is set `Yes`, the collection is made automatically during updating of a device configuration. `Speed` and `High speed` fields show information about an interface speed. The value are updated automatically, when `Update speed` field has `Yes` value. `Main interface` field, for subinterface, shows physical interface, on which it is defined. For physical interface it shows itself, and then in the field description *myself* appears.

Device IP	Forbidden IP	Address	Network mask
✓		191.6	55.25

IP panel includes a list of IP addresses with masks of networks ascribed to the network interface.

`Device IP` column shows, if a given address is treated as a device address or not. If yes, the device is polled by selected IP address. The device can have such address only one. `Forbidden IP` column shows addresses, that are never used during polling of the device. `Device IP` column shows, if a given address is treated as a device address. Then, the device is polled by a selected IP address. A device may have at the most one the address. `Forbidden IP` column shows addresses, that are never used during polling of the device. If you want to change one of properties of a given address, you should click an address entry in a suitable column.



Agg. collections tab shows a list of aggregate collections, to which an interface belongs to. The panel shows a list and its buttons, that allow to edit it. If you add a network interface to an aggregate collection, data collected for the interface increase suitable date of the collection. So, it is a sum of them.

You can't see a list of all network interfaces available in **Network Information Database**. However you can see all interfaces of a given device, when you run a preview. To do this you should double click on a device symbol on the **Network Management Map** or select a device and choose suitable items of a menu or suitable button on the toolbar.

### 12.5.8. BGP peers configuration

The screenshot shows a window titled "BGP peer" with a sidebar on the left and a main table area. The sidebar contains icons and labels for "Specific", "Alarm", "State", "User and group", "Rights", "Rights to State", "Rights to Alarm", and "Additional groups". The main table displays the following data:

Parameter	Value
Local IP address	212.191.126.5
Remote IP address	212.191.126.1
Description	Lodz-gw
Remote AS	8501
Admin status	Start
Oper state	Established
Local network interface	lo0.0

At the bottom of the window, there are three buttons: "Apply and Close", "Apply", and "Close".

BGP peers always belong to physical routers discovered by [dnmmsd](#) server. They have many features and properties resulting from both their equivalents on physical devices and David system functionality. The field Local IP address shows a local IP address of defined BGP peer, and Remote IP address field - its remote address. Description field is set by a system user. Remote AS field

shows an AS number of a given peer while `Admin status` and `Oper status` a current operation and administration state (i.e. ACTIVE, ESTABLISHED, UP). `Local network interface` field shows a local network interface, that has IP address consistent with `Local IP address` field.

You can't see a list of all BGP peers available in **Network Information Database**. However you can see all BGP peers of a given router, when you run a preview. To do this, you should double click on device symbol on the **Network Management Map** or select a router and choose suitable items of a menu or suitable button on the toolbar.

### 12.5.9. Managed item configuration




The screenshot shows a window titled "Managed item" with a sidebar on the left and a main table area. The sidebar contains the following options: Specific, Entries, Alarm, State, User and group, Rights, Rights to State, Rights to Alarm, and Additional groups. The main table has two columns: "Parameter" and "Value".

Parameter	Value
Adding zero to OIDs	As group
Link type	Network interface
Link ID	7
Link (translated)	Serial1/2

At the bottom of the window, there are three buttons: "Apply and Close", "Apply", and "Close".

Managed items are results of scanning process of a physical device that concerns a given managed item group. Their properties and fields depend on a definition of origin group. Specific tab includes a few fields, common for all types of managed items. Adding zero to OIDs field shows if for the managed item is added '0' to its index during SNMP-GET operation (On), or not Off. A value which is used the most often is As group, i.e. a procedure consistent with the group definition. Link type field shows a link type if a given item is connected with other item, and Link ID field shows an identifier of a connected item. Link (translated) field is a resulted description of the item to which is connected a selected managed item.



Entries tab shows a list of entries, that belong to the managed item. Definition of origin managed item

shows which one can be edited or not. The fields usually can be edited. Columns `Minimum range` and `Maximum range`, if they are different from each other, they overwrite ranges defined by the origin group. It lets you set a range of acceptable values for each item separately. `Accounting type` column lets you set type of accounting for each item. If it is `None`, this value is taken from a definition of a appropriate entry of the origin group.

## 12.5.10. Objects configuration

The screenshot shows a window titled "Object" with a sidebar on the left containing icons and labels for various object properties: Specific, Dependences, Alarm, State, User and group, Rights, Rights to State, Rights to Alarm, and Additional groups. The main area contains a table with two columns: "Parameter" and "Value".

Parameter	Value
ID	120
Type	Device
No of children	0
Update name	Yes
Discovered (network only)	No
Background	
Device type (device only)	Ethernet switch
X coord	77
Y coord	-343
Width	0
Height	0
Collected	No
Update coll. avail.	Yes
Collect group	<null>
Last update	2008/03/07 13:04:35
Physical device	<null>

At the bottom of the window, there are four buttons: "Apply and Close", "Apply", "Close", and "Add as new".


Objects can be both physical devices discovered by the system and symbols created by a user for the system needs. The following types of objects are permitted: `Network`, `Link`, `Device`, `Location`. A user can create objects of `Link` or `Location` type. If you want to create an object of `Location` type, you should specify suitable fields to edit. If you want to define an object of `Link` type, you should select additionally two objects that are its ends. A new object always is added to a current presented map.

In `Specific` panel the field `Type` describes an object type. `Update name` shows if its name is updated during its update of the configuration, and `No of children` shows us how many children objects are included in the object. `Discovered (network only)` field concerns only objects of `Network` type and shows if a network is scanned to find new objects or not. `Background` field specifies a path to a local graphic file, that is a background of the object inside. The field `Device type` describes a device type, if the object has `Device` type. The field can have the following values:


- Generic device;
- Computer;
- Router;
- ATM switch;
- Ethernet switch;
- Ups;
- Print server;
- Wireless device;
- Modem.

In the moment of discovering of a device by the system, it tries to find a correct value of the field, that next can be changed by a user.

The fields `X coord` and `Y coord` show an object location on a mother map. `Collected` field shows if collected data for the object are compatible with `Collect group`. `Update coll. avail.` field shows if during update of the configuration of a device, the best collection group will be searched for it every time. `Last update` field means for objects which reflect physical devices and the field shows when the last update of a device had taken place using SNMP protocol. `Physical device` field shows an object which is a physical device for a given object. Selecting in this field other object by a user is understood, that the edited object is set as a virtual object. The function is used when virtual routers of Juniper company are monitored. In the case of `Link` object type you can use additionally two fields (`Link from` and `Link to`) describing objects that it connects.




Dependencies panel presents a list of items that their states influence on an object state. Besides the list, states of object children, network interfaces and managed items (if an object is a physical device) and BGP peers (if additionally the object is a router) influence on the object state. Two buttons are placed below the list. The first one helps you edit the list and second one lets you delete selected items. A list edition opens a dialog with the list of all current available items from Network Information Database that you can use in this place, and the dialog will be described below.



A list of items can be a multiple-choice or a single-choice. It is depended on a given context in which it was opened. An exploration of branches is depended on the same fact. If you want to apply that changes,

you should press the button `Apply`, otherwise you should press button `Escape` or click the mouse behind an area of the dialog.

### 12.5.11. A configuration of ping object groups



Ping object groups group objects in logical sets. Each group is displayed as a separate panel of objects. It defines any common properties for gathered objects. `Specific` tab has many fields which meaning is described below:

- Name - a group name;
- Alarm interval (seconds) - it defines about what period of time alarms will be run for objects belongs to that group;
- Number of packet - a number of packets;
- Packet size - a size of packets;
- Interval between packets (ms) - it defines about what period of time single packets in each burst (series);
- Timeout (ms) - timeout for a single packet;





- Interval between series (sec) - interval between next series of packets;
- Log results - it shows if response times will be logged or not;
- Can send Traps - it shows if SNMP Traps can be sent or not;
- Bad status upper limit (%) - upper limit of BAD status in percents;
- Down status upper limit (%) - upper limit of DOWN status in percents;
- Ok limit for min (ms) - a limit of acceptable minimum response times;
- Ok limit for avg (ms) - a limit of acceptable average response times;
- Ok limit for max (ms) - a limit of acceptable maximum response times;
- X coord i Y coord - X and Y coordinates of ping object panel;
- Width i Height - width and height of ping object panel.

### 12.5.11.1. A list of available ping object groups




A list of ping object groups presents ping object groups sorted according to their names. Properties of items are shown in the columns. Selected items of a list can be edited in [Ping groups](#) window. Two buttons are placed below the list of items.

**Table 12.24. A description of the Ping groups window buttons**

Button	Description
	It opens Ping group window, that you can also open in the main view of the application.
	It allows you to delete selected items of the list. It can be more then one item.


### 12.5.12. Item alarms configuration



A part of edited windows of different items has Alarm tab. There is data concerning alarms, i.e. programs, that are periodically run for items which state has CRITICAL value. The alarm programs are run by [dnmmsd](#) server. Frequency of running alarms is a property of a ping object group when the alarm is called for a ping object. For other items (network interfaces, BGP peers and managed items) the value is fixed and it is 5 minutes.

To turn off alarm for an object to a given moment, Yes value should be set for Alarm off field, and then in Turn the alarm on (days) field should be chosen a day and in Turn the alarm on (hours) field - an hour when the alarm is active again. Turn the alarm on at field shows additionally a day and an hour, when the alarm is activated. When Alarm off until OK field has Yes value, alarm will be active 15 minutes after last change of an object state from CRITICAL state. When Alarm always off field has Yes value, the alarm will be never run for the object. Alarm counter field shows a counter of run alarms for the item. Last alarm field shows last time of alarm for the item. Last down state filed shows last time of CRITICAL state for the item. Run test alarm field allows to run a test alarm for the item.


### 12.5.13. Item states configuration



Parameter	Value
Id	1662
Name	
State group	default
State	OK
Is passive	No
Community	<null>
Last check	2008/02/15 14:30:17
Last status change	2008/02/15 14:30:17
Owner	Switch 1


A part of edited windows of different items has `State` tab. It includes information about a state of the item and allows to specify some properties, that are common for almost all items. `Name` field includes an item name. For some types of items (i.e. BGP peers) the field is empty, because its value is unimportant. `State group` field shows a group of states to which a given item belongs to. `State` field includes an item state, and `Community` field can include a name of Community object assigned to the item. `Is passive` show if state of the item may be actively changed and affect state of its owner. `Last check` field shows when for the last time a given item state was checked. `Last status change` field shows when for the last time change of a given item was observed. `Owner` field includes owner's data (a parent object) of an item.

### 12.5.14. A configuration of a user and an item group




Edited windows of all items of **Network Information Database** include User and group tab. Creator (UID) field shows a creator of a given item, and Modifier (UID) field - the last person who modified an item. system value shows, that a creator or a modifier is dnmmssd server. Creation time field shows a creation time of an item, and Modification time field - its modification time. User field specifies an owner of the item, and Group field - a group to which the item belongs to.

### 12.5.15. A configuration of additional groups of item



Additional groups tab exists in edited windows of all items. It allows to add an item to additional groups of users and describes access rights for each group separately.

### 12.5.16. A configuration of access rights to the Database objects



Rights tab exists in edited windows of all items. It allows to specify access rights to an item for an owner, a group or other users. Each of groups can have a right to WRITE, READ and EXECUTE of a given item. Minimum user's level field specifies a minimal level of a user that can modify an item. The word 'minimum' can be mistaken because a level 0 of a user is the highest level of rights, and next levels (it means  $n+1$ ) define lower levels of rights.

## 12.6. Description of ping object panels



Each panel of ping objects agrees with groups to which the objects belong to. A name of the group is the window name. You can select many objects using the mouse and edit their properties. Double clicking on an object opens the [edit window](#). If you click on the panel outside of any objects with the mouse, you will unselect all selected objects. You can move objects between panels (groups) in the easy way selecting objects and dragging them to a given panel (drag and drop).

Ping objects represent IP addresses, to which ICMP ECHO packets are sent. The objects can be a result of discovering monitored devices by the system (one IP address will be chosen from among IP addresses of discovered device), or it can be created by the user directly.

If you click double on ping object, the dialog window is shown. Specific panel presents basic properties of the object.

Parameter	Value
ID	6
Net interface	<null>
Group	Default
Audio name	
Hostname or IP address	68.
Status	OK
Received / Sent	5 / 5
RTT in ms (min / avg / max)	5.784 / 7.108 / 8.902

- Net interface - it shows in which interface of a given device, the object is connected. The field the most often shows end results of device discovering by the system.
- Group - it shows, to which group the object belongs to. Object belonging to the same group are presented inside of the same panel. The groups may defines conservation of the objects which belong to them.
- Audio name - it allows to give a string, that is read by a speech synthesizer when an alarm for the object is run.
- Hostname or IP address - it shows IP address, to which ICMP packets are addressed.
- Status - it is only to read and it includes information about object status (a percent of responses/sent packets).
- Received/Send - number of received/sent packets.
- RTT in ms (min/avg/max) - round trip-time expressed in miliseconds (minimum/average/maximum).

Each ping object is represented by some graphic information about it.



There is a rectangular area in the bottom in which on the top an object name is placed and below it, in




bracket, its IP address. A color of the rectangular area will change on purple, when the object status is BAD. When the status is DOWN, the color will change on red and start flashing. When the object has Not managed state, the color will be gray.

The post from the left side shows a percent number of received responses. Lacking percent of responses that remains to 100%, is marked as a flashing part of the post. From the right side of the post is shown a percent of responses numerically in green color.

The rest part of the post is filled by a graph with three numbers describing it. On the bottom from the left side of the graph, the last middle responding time of a ping object is placed, and it is counted in milliseconds. The rest two values written in a white font describes a maximum (at the top) and a minimum (at the bottom) of the graph. Near the post crossing out symbol of a loudspeaker can appear. It shows that an alarm is turned off for a given object. A coloring of the symbol points at a kind of an alarm that was turned off.

There are three letters on the graph from the right side: m, A and M, that mean (m)Minimum, (A)verage and (M)aximum. They show if limits of response times are exceeded (red color) or not (green color). The limits are common for the group of ping object.

## 12.7. A window presenting a list of logged in users on dnmsd server



The application allows you to preview users logged in [dnmsd](#) server. The window has a few buttons allowing to some operations.


**Table 12.25. Description of Logged in users window buttons**

Button	Description
	It lets you refresh a list of logged in users.
	It turns on/off automatic refreshing of the list every 10 seconds.
	It lets you logout a selected user.


The particular columns of a user list describe:

- Username - a user's name;
- Gecos - a count description;
- UID - a user's identifier;
- ULEVEL - a right level of a user;
- Login time - login time of a given user (it can't be equal a connecting time with the server if an authentication took place more then one time);
- Last activity - time of the last user activity (for a given application instance) on dnmmserver. It's understood as sending of any message to the server;
- Server ID - an identifier of a given application instance on [dnmmserver](#) server (the same user can be logged in using more then one the application instance).

## 12.8. A configuration of xdnmm application

The button  opens the configuration window which consists of two configuration panels.


### 12.8.1. A configuration of dnmmserver parameters



At the top of the dialog is placed a list with two options that lets you choose a way of connecting with [dnmmserver](#) server. The first one allows you to connect with the server by a socket file which a name you can write below. The second one lets you connect with the server by a computer network. Then you should pass a computer name or its IP address and a number of TCP port on which the server works on a given

computer.

### 12.8.2. A Read-Only mode configuration



Read-Only mode enabled field shows if a Read-Only mode is turned on or not. If it's active, it will run in a Read-Only mode when a time specified in Idle time (seconds) field goes on. If you want to make changes in **Network Information Database**, you should login again on [dnmmsd](#) server.

## 12.9. Related articles

[Service of Network Management Map \(dnmmsd\)](#)

---

# Chapter 13. Network Nodes Viewer (xdnnv)

## 13.1. General

**xdnnv** application is **Network Nodes Viewer (xdnnv)** and it is a part of **Network Manager**. The application using a configuration file previously created by [xdnnve](#) generates the application which controls work of monitored network devices provided SNMP protocol. Applications generated in that way can be extremely different from one another both their appearances and their functionalities. However, there are some common functionalities for all such applications that let user have some control during their work. Control panels of network devices consist of controls that work is described in the section concerning [xdnnve](#) application.

## 13.2. Synopsis

**xdnnv** can be run with the following options: [\[-V,--snmp-version version\]](#) [\[-d,--dump-packets\]](#) [\[--debug-snmplib\]](#) [\[-D,--no-communities\]](#) [\[-T,--no-toolbar\]](#) [\[-S,--no-statusbar\]](#) [\[-l,--log-facility log\\_facility\]](#) [\[-L,--log-level log\\_level\]](#) [\[-H,--host hostname\]](#) [\[-R,--read-community community\]](#) [\[-W,--write-community community\]](#) [\[-s,--stick sticking\\_string\]](#) [\[--oid-of-control control\\_name=oid\]](#) [\[--caption-of-control control\\_name=caption\]](#) [\[-v,--version\]](#) [\[-h,--help\]](#)

## 13.3. Options

Table 13.1. **xdnnv** options

Option name	Description
<i>-V,--snmp-version version</i>	Use a specified SNMP: SNMPv1 (1) or SNMPv2C (2c) (default: 2c).
<i>-d,--dump-packets</i>	Dump information about each single SNMP packet in the ASN.1 notation on stdout.
<i>--debug-snmplib</i>	Turn on debugging of a native SNMP library, i.e.: currently library used by SNMP wrap library of David system.
<i>-D,--no-communities</i>	Don't display communities.
<i>-T,--no-toolbar</i>	Don't show the toolbar.
<i>-S,--no-statusbar</i>	Don't show the status bar.
<i>-l,--log-facility log_facility</i>	Choose log facility: daemon   user   local0   ...   local7 (default: local6).
<i>-L,--log-level log_level</i>	Choose log level (on stderr and syslog) i.e. messages of selected level and more important levels will be logged: emerg   alert   crit   err   warning   notice   info   debug0   ...   debug2 (default: warning).
<i>-H,--host hostname</i>	Specify a hostname you want to communicate (domain name or IP

Option name	Description
	address).
<i>-R,--read-community community</i>	Use a specified community for reading.
<i>-W,--write-community community</i>	Use a specified community for writing.
<i>-s,--stick sticking_string</i>	Stick this string to ID strings of selected controls.
<i>--oid-of-control control_name=oid</i>	Set a specified OID to a control that has a specified name.
<i>--caption-of-control control_name=caption</i>	Set a specified caption to a control that has a specified name.
<i>-v,--version</i>	Display version number on stderr and exit.
<i>-h,--help</i>	Display this help and exit.


## 13.4. Description

One of the first step during building of a panel is creating sessions according to parameters saved in the configuration file. Each session owns some properties. Some of them can be unspecified or can get default values during the panel [configuration](#) by [xdnnve](#). It concerns the following cases:

- if SNMP version is given as `Unspecified`, SNMP version of the session is set according to an argument of `-V` option of `xdnnv`;
- if no hostname is given, an argument of `-H` option of `xdnnv` becomes the hostname;
- if no SNMP community is given, an argument of `-R` option of `xdnnv` becomes the community for `Read` type sessions and an argument of `-W` option of `xdnnv` becomes the community for `Write` type sessions;
- if no sticking string is given, an argument of `-s` option of `xdnnv` becomes the sticking string.

After specification of the panel properties the following procedures come: creating controls, assigning to particular sessions such controls that want to be used in `Read` or `Write` actions and building expected connections between controls (i.e. Scroll bar, Slider). Next, lists of SNMP packets are built for particular timers of the panel. That SNMP packets are going to be sent to particular devices during the panel work.

After that initialization the panel starts its work according to [timers settings](#) saved in the configuration file and interacts with its user.









The application allows to control in same way work of a generated panel. Mostly, it can be a control of application timers and SNMP packets traveling between devices and the application and you can also trace timeouts for sending requests and other statistics.

Buttons on the toolbar help you to keep control of the panel work. The first button agrees with File menu:

**Table 13.2. xdnnv - File and Utilities menu buttons**


Button	Description
	It lets you exit the application.
	It opens Sessions statistics dialog that shows you current statistics of ingoing/outgoing packets.

Button	Description
	It opens A basic timer list tab of Configure properties dialog.
	It opens Counters tab in Configure properties dialog.
	It opens Sessions and PDU-s tab in Configure properties dialog.
	It opens Timeouts tab in Configure properties dialog.
	It lets you clear the contents of all controls on the panel.
	It allows you to clear timeout counters for all controls.

View menu includes two options - Show tool bar and Show status bar - they allow you to display or hide the toolbar and the status bar.


Through Help menu you may find out about the application version and its creation time.

### 13.4.1. Sessions statistics



The application counts ingoing and outgoing packets, occurred errors and timeouts. You can watch current statistics by Sessions statistics dialog. The panel creation time is displayed at the top of that dialog.


### 13.4.2. A basic timer list tab



Configuring by [xdnnve](#) the timers for the panel and connected with them Read and Write actions, you specify a timer interval on which particular actions will be run. If the interval is lower then 2 seconds, it


means that a given action will be run only one time on the beginning the panel work. Turn on the Timer option is set if the interval of a given timer is lower then 2 seconds. The timers intervals can be changed during **xdnnv** work but the effect will take place only after rebuilding of all SNMP packet lists. You may do this selecting the item of the timer list and setting its interval. Pressing Apply button lets you apply changes.

### 13.4.3. Counters tab



This tab allows to clear specified counters by selecting a specified kind of counters and pressing Clear selected button.

### 13.4.4. Sessions and PDU-s tab




This tab lets you see current state of all built SNMP packets and find out to which session a given packet belongs and for request of which control it was built. Each packet has its identifier that appears in the first column of a presented list (A sessions information and ID with each Pdu was sent last time and its content). Valid column shows whether a given packet is valid or not (sent or not). Type column shows a type of packet (two possibilities: Normal and Control; the second type allows to control and build tables). Full column tells whether a given packet includes a maximum number of MIB identifiers (this value is predefined and it can't be changed). Timer interval column shows a number of seconds which elapses between sending this packet each time while Timer ID



column shows this timer identifier (an internal value of the application). The last column OIDs origin presents controls separated by commas for which requests a given SNMP packet was built.

Using `Timer interval in sec. group`, Turn on the `Timer option` and `Valid option` you can control a given SNMP packet according to meaning of a specified column of the list. Pressing `Apply` button confirms these changes. Pressing `Rebuild all Pdus` causes rebuilding of all SNMP packets for the panel.

### 13.4.5. Timeouts tab



Timeouts tab shows timeouts for particular controls. Pressing `Clear timeouts in all controls` clears timeout counters for all controls. At the top of the tab the last clearing time is displayed.

## 13.5. Related articles

[Network Node Views Editor \(xdnnve\)](#)

---

# Chapter 14. Network Node Views Editor (xdnnve)

## 14.1. General

**xdnnve** is **Network Node Views Editor** and it is a part of **Network Manager**. This is a graphic tool application which is a kind of an editor for some resources such as control panels for network devices. The application allows you to build different configuration files. [xdnny](#) on the base of the configuration files generates applications to manage control panels.

## 14.2. Synopsis

**xdnnve** can be run with the following options: [*-L,--log-level log\_level*] [*-v,--version*] [*-h,--help*]

## 14.3. Options

Table 14.1. xdnnev options


Option name	Description
<i>-L,--log-level log_level</i>	Choose log level (on stderr and syslog) i.e. messages of selected level and more important levels will be logged: emerg   alert   crit   err   warning   notice   info   debug0   ...   debug2 (default: warning).
<i>-v,--version</i>	Display version number on stderr and exit.
<i>-h,--help</i>	Display this help and exit.

## 14.4. Description

### 14.4.1. Starting up and terminating the application

**xdnnve** reads its configuration parameters from `.xdnnverc` file during its startup. These parameters concern appearance of the program and other working parameters (i.e. the last edited file). The application expects to find its configuration file in a directory which name is kept in environmental variable `$DAVIDPRIVDIR`. When the file doesn't exist, the application begins its work with an empty document and with its default settings. When **xdnnve** finishes its work, it writes its current settings in the `.xdnnverc` file. The application, during its work, can write some errors on stderr instead of displaying message boxes.

## 14.4.2. Main window work



A configuration files edition, on which control panels are generated, is made invisible for a user. A user builds a panel putting controls on it by using the mouse and specifying their properties and connections. All operations are made using a graphic interface and a user doesn't need to know a structure of edited files.

The main panel takes a central part of the application main view. The toolbar is usually above the main panel while the status bar is placed below it. On the left side of the main panel tool buttons are placed. They help you to create your control panels.





Some information is displayed on the status bar: coordinates of a left, top corner and a size of an object over which there is the mouse pointer. When no object contains the mouse cursor, coordinates and a size of the main panel are displayed on the status bar. There is only one exception when a rectangle area is marked using the mouse. Then, the displayed data are applied to it.

### 14.4.2.1. Main window buttons

Buttons on the toolbar allow you to edit a created panel. The first four buttons agree with `File` menu.

**Table 14.2. xdnv - File menu buttons**











## Network Node Views Editor (xdnnve)

Button	Description
	It lets you close the program. A user will be asked earlier for saving some changes of an edited file (if he has made any changes).
	It allows you to create a new configuration file.
	It helps you to open the configuration file.
	It allows you to save the edited file as the same file (in case of a new file a user will be asked for specifying its name).
Save as	It doesn't appear on the toolbar, and it allows you to save information to a file which name is specified by a user.

The edited operations applies to specified objects. When there aren't the objects, the edited operations applies to the main panel. An object is marked when the mouse cursor is above it (exactly: the object has a focus). An object permanently can be marked when any part of it belongs to a rectangle area of the main panel drawn by pressing the left mouse button. The specified object can be selected or unselected pressing the left mouse button while the `Ctrl` key stays pressed. Specified objects can be unselected by clicking the mouse on the main panel or marking a new area of it.

Rest of buttons agree with `Edit` menu and they are shown below:


**Table 14.3. xdnnve - Edit menu buttons**

Button	Description
	It allows you to cut a specified item. A dialog will appears earlier and you will be able to confirm the operation. The dialog can also appear in the other cases.
	It lets you copy a specified item.
	It lets you paste a copied item.
	It helps you to delete a specified item.
	It allows you to delete all items of a created panel.
	It helps you to place an edited item on the first plan before other controls.
	It lets you place an edited item under other controls.
	It allows you to transform selected items to a specified type of a control.
	It helps you to configure properties of a specified control or panel.
	It allows you to test a created panel.


You can use `Edit` menu options by pressing the right mouse button on the selected control or the panel. Then a list with accessible options of the menu is displayed.


Through `Help` menu you can find out about the application version and its creation time.

## 14.5. Main panel configuration



A frame style of the main panel you can specify choosing [Frame](#) tab which was described later in next part of the document.





`Specific` tab allows you to define many parameters of the main panel that will influence a work of created control panel. You can set colors of the panel or choose its default color. You can set a name of a graphic file which will be the main panel background. If you want that the main panel will be able to poll every some period of time devices to update presented data, you should define at least one session. In this aim you should press the button  in `Sessions` group to define a new sessions.



A sessions property dialog appears that you should pass a session name (it is only essential to identity within the panel), SNMP version, a name or an address of a device to which SNMP packets are sent, a type of requests (Get - to read an operation and Set - to write an operation) and a community. Sticking string field allows you to pass a text that can be used as the text to paste to OID-s' controls during [actions](#) are run. Fields that must be specified are: a session name (Name), a version (Version - choosing Unspecified field you don't have to choose a concrete version) and a version type (Type). During a generation of a real working panel unspecified fields are completed by input parameters of [xdnnv](#). This fact applies when you create one panel for many devices of the same type where only the following fields will be changed: a version (Version), a name of device (Host), a community (Community).


In Sessions group of Specific tab the following buttons are placed:


**Table 14.4. Sessions group buttons**

Button	Description
	It let you move up a given item.
	It let you move down a given item.
	It lets you delete a selected item.
	It lets you modify parameters of selected session (then A sessions property windows is opened).

In Timers group you can add a new timer or delete an existed one. For each timer you can set an

interval counted in seconds. An interval lower than two seconds shows that the actions from `Actions` group, connected with this timer, are taken only one time in the moment of the panel creation. When you delete a given timer, you delete also the actions connected with it. If you choose a next timer while the choosing one earlier has got no actions, the timer will be destroyed automatically.

In `Actions` group you can set tools to manipulate an action list of a given timer. They allow you to move up and down items of a list, delete a given item of the list and add a new one. The button  lets you add a new item (an action) to the list and then a menu with two options: `Read` and `Write` is appeared. The first one includes a sessions list to a reading operation of values for specified objects to update them on the panel (an operation `Get` in SNMP) and the second one includes a sessions list to a writing operation i.e. sending values of specified object to monitored devices (an operation `Set` in SNMP). In the most of cases the second list is empty.





















When you specify a given session you look `Choose objects` dialog that allows you to choose specified controls among all accessible in a given moment on the panel. After choosing controls a command of actions will be added to a list of a given timer.

## 14.6. Configuration of controls common properties


You can build a panel using controls which there are on the left side of the main view of the application. You should press only a selected control and click with the left mouse button above the area of the panel. When you draw a rectangle area instead of clicking the mouse, a control fills this rectangle area itself. You can use the controls as follows:

**Table 14.5. Description of the controls**

Control	Description
	Pointer

Control	Description
	Line edit
	Label
	Push button
	Progress bar
	Check box
	Combo box
	Group box
	List box
	Radio button group
	Scroll bar
	Slider
	Spin box
	List view
	LCD number
	Graph
	Control light
	Line


The first button isn't a button of a control but it allows you to unselect a pressing button of a given object.

If you press the button  and choose any control or double click above the area of a control with the left mouse button, you can configure a choosing object. For all controls a window with 3, 4 or 5 tabs is appears. `Main`, `Style` and `Specific` tabs appear for each controls. `Actions` tab almost always shows while `Frame` tab shows only in some cases. A list of displaying tabs for particular controls is shown below in the [table](#) in the next part of the document.

`Main`, `Style`, `Actions` and `Frame` tabs look similarly for all controls (an exception is `Main` tab and remotely `Actions` tab) while `Specific` tab is different for each of controls.

## 14.6.1. Main tab





In `Main` tab is placed `Object name` field, that lets you specify an object name. An object with the name will be available for other controls and the panel. You can set also a kind of a font (`Fonts` button) different from default one. If an object is connected with SNMP i.e. if it is used as an argument of `Read` action or `Write` action, you can pass its `ID string`. If an object is used to set a value of SNMP (`Write` action), you must set a type of this variable by choosing an option of `Object type` field. You should set `Accept incoming Pdu` to update an appearance of the object basis of working results of `Read` actions. Sometimes you can want to paste an additional `OID` to `ID string`. Then you must set `Accept ID string sticking` in object properties. You should pass also a session name in `Belongs to session` to use an object in any action `Read` or `Write` type.

In `Text/value on timeout` field you can pass a value that a control will receive when it doesn't receive a response from a polling device in expected time. This value will be interpreted as a text when a control (i.e. `Label`) expects these values otherwise the value will be interpreted as a numerical value.

In `Text/value after timeout` field you can pass a value that a control will be received after timeout when it doesn't receive a response from a polling device.


## 14.6.2. Style tab



Style tab includes a field of choice that gets you four possibilities of receiving of Focus for a given controls: a lack of focus, focus by pressing Tab key, focus by pressing the mouse button and two last options together. In Caption dialog you can pass an inscription which is displayed on a given control (it concerns a part of objects). In ToolTip dialog you can pass a text which is displayed in an response dialog above the object when you drag the mouse cursor on it (empty inscription means a lack of a response). Turning on Enabled option allows you to set a given control in an accessible state by the mouse or the keyboard.

Three buttons are placed on the tab and they helps you to set free color for any controls. Each of the buttons let you specify color which is characteristic for a state in which any controls can be (active, passive and normal).


### 14.6.3. Actions tab




In Actions tab for each event you can specify a list of actions that will be done. Events for controls mostly can be in two kinds: pressing the left mouse button while the Enter key stays pressed and double

clicking the left mouse button. The second event in the case of the mouse always must be preceded the first one. It can cause a situation that actions joined to a double clicking cannot occur or they quickly occur after actions for a single clicking. For this reason you shouldn't define actions for this both events in the case of the same object.


A user has five different kinds of actions at his disposal. Only some type of objects have all kinds of actions. `Close` action allows you to finish a work of the panel. If the panel is like a dialog, it only closes itself. If it is like a main panel, a work of the whole application is finished. `Read` action lets you read data of specified objects to update their current view on the panel. `Write` action passes this data to a managed device.




`Program specification` `Program specification` window defines `Exec` action and it allows you to specify the program and its parameters that will be run during a given event is done. When you specify a program and its parameters, you can pass names preceded \$ sign. A name can be: an environmental variable that will be defined during the panel is working, a control name which a value we want to use, a keyword as `HostName`, `ReadCommunity`, `WriteCommunity`, `FileName`, `StickingIDString` including appropriate input parameters of [xdnnv](#).



`Network Node View parameters` window defines `Dialog` action and it allows you to pass names of a configuration file for [xdnnv](#) describing the main panel. You can choose `Stick this ID string` option and pass `OID` that will be pasted to controls of a given panel. As in case of `Exec` action, you can use \$ sign and pass after it names of controls or keywords (you can't use environmental variables). `Dialog` action runs a service of a specified panel in a modal dialog in contrast to `Exec` action which runs some program.

The buttons of **Actions** tab allows you to manipulate a list of actions for a given event. The button  lets you define a new action among described above. You can specify **Read** and **Write** actions in the same way like the [panel configuration](#).






### 14.6.4. Frame tab





Frame tab lets you configure a frame style of an object and its line width that a frame will be built. In Style group you have some possibilities at your disposal: No Frame, Box, Panel, WinPanel, HLine, VLine, Styled Panel, PopupPanel and frame styles as: Plain, Raised and Sunken. In Line group you can define an outside line width of a frame and in Midline group - a middle line width. An effect of current settings is shown on the preview.

### 14.6.5. Tabs for particular controls

Table 14.6. Tabs for particular controls

Control	Main tab	Style tab	Actions tab	Frame tab	Specyfic tab
 - Line edit	✓	✓	✓		✓
 - Label	✓	✓	✓	✓	✓
 - Push button	✓	✓	✓		✓
 - Progress bar	✓	✓	✓	✓	✓
 - Check box	✓	✓	✓		✓
 - Combo box	✓	✓	✓		✓
 - Group box	✓	✓		✓	✓
 - List box	✓	✓	✓	✓	✓


Control	Main tab	Style tab	Actions tab	Frame tab	Specyfic tab
 - Radio button group	✓	✓	✓	✓	✓
 - Scroll bar	✓	✓	✓		✓
 - Slider	✓	✓	✓		✓
 - Spin box	✓	✓	✓	✓	✓
 - List view	✓	✓		✓	✓
 - LCD number	✓	✓	✓	✓	✓
 - Graph	✓	✓	✓	✓	✓
 - Control light	✓	✓	✓	✓	✓
 - Line	✓	✓	✓		✓

## 14.7. Specific tabs for particular type of controls

### 14.7.1. The Specific tab for Line edit control




- **Line edit** control allows you to edit a text of a single line.




Echo field of Specific tab lets you set if during a text edition the characters be able to write (Normal) or not (No Echo) and whether asterisks be able to display instead of a text (Password). The tab helps you to set a maximum value of characters (Maximum character count) that can be

written by a user. You can also choose if `Line edit` is surrounded with a frame (`Frame around this single line edit`).


### 14.7.2. The Specific tab for Label control


 - `Label control` displays one or more rows of a text or a picture.



`Specific` tab allows you to pass a path to a graphic file or use a preview button to choose the file using a dialog. If a graphic file can be displayed, it will replace a text of a control. If a text is displayed, you will set a kind of paragraph and whether a text be able to split into lines including whole words. You can do this using buttons from `Alignment` group. `Transparent control` option lets the control be transparent. In a case when a text is displayed, a background of the control won't be shown while in a case when a picture is presented, the control only will exist in points that the picture isn't transparent.


### 14.7.3. The Specific tab for Push button control

 - `Push button control` confirms a user's choice.




The tab lets you pass a path to a graphic file like in a case of [Label](#). It allows you to choose whether the control can be a default button for a dialog or it can be `Toggle button`. In this case you must pass equivalent of some integer number for each of states.

#### 14.7.4. The Specific tab for Progress bar control




- Progress bar control mostly shows current value


(greater or equal zero) of a specified parameter.



Orientation group of Specific tab gives you two ways of Progress bar presenting: Vertical or Horizontal. The control must have a maximum positive value (a minimum one is always equal zero). The value can be passed as fixed or it can depend on an object value of monitoring device when its identifier (OID) is passed. When you want to build this identifier through sticking some string, you can choose additionally Accept ID string sticking field. In Text group you can pass one of three possibilities of a current value displaying: without a text, an absolute value or a percent value.

### 14.7.5. The Specific tab for Check box control

 - Check box control is a toggle button and allows you to select or unselect a specified option.




Check box is a control similar to [Push button](#). So, Specific tab lets you pass a graphic file which is displayed instead of a text. Because the control has two states, you must pass some integer numbers for each of states.

### 14.7.6. The Specific tab for Combo box control



- Combo box control allows you to choose a specified item of available items list.







Style field of Specific tab allows you to choose one of three accessible styles. Motif 2 (read-write) style lets you edit Combo box control. In this case you can choose automatic adding of a completion from an available items list (Auto completion field). You must also pass how many lines a field of a control list will be high (Line limit field) and you must assign a number to the first line in Read-Write mapping group. This assignment allows to imitate values on a text from an available items list (this object sends by Write action and receives by Read action an integer value unless the list is created dynamically).

The edited field allows you to pass specified items of the list. If the list of items is created dynamically, you must choose Dynamic list field. Then Combo box ID string allows you to build items of the list. The object identified by the ID string means as the first item of MIB chart, that will be transformed into an item list of the control through the next SNMP requests of Get-Next type.

### 14.7.7. The Specific tab for Group box control




- Group box control groups objects.




Specific tab allows you to choose a kind of a title alignment as regards an object width. A text can be aligned to left or right side or central.

### 14.7.8. The Specific tab for List box control




- List box control lets you set an item of a list.



In Read-Write mapping group of Specific tab you should pass an index value of the first item to which a control value will be mapped during its recording or reading (similarly as in [Combo box](#) control). A static item list you can pass in Items dialog. If you want to create a dynamic list, you should choose

Dynamic list. A creation procedure and working of the list was shown describing [Combo box](#) control.

### 14.7.9. The Specific tab for Radio button group control



- Radio button group control lets you choose one of

options available in a group.




Text alignment field of Specific tab lets you set a specified kind of a title alignment. You can also create a list with accessible options passing names of objects in Radio buttons group and you can set an order of their indexing and ascribe an initial index number to the first object (Start indexing from field). A defined Radio buttons you can configure by double clicking it the left mouse button. Then you can pass a path to a graphic file that is displayed instead of a text. Each object like that you can move and change its size but only within Radio button group control.

### 14.7.10. The Specific tab for Scroll bar control



- Scroll bar control lets you manipulate other control value and

present a current value between defined ranges.




In Range group of Specific tab you can pass limited values (a minimum and maximum value). In Steps group you should set quantity of steps and in Orientation field - a kind of the control orientation. There are a list of objects connecting with the control and buttons to manipulate the list items in Connected controls group. These objects will react to moves of the control slide. Objects receiving new values of Scroll bar update their view depending on their specific properties.

As in case of [Progress bar](#) you can set that limited values will be able to change dynamically (in case of [Progress bar](#) you have one limited value while the second value is always zero). A description of Scroll bar and its list of items created dynamically is described in [Progress bar](#) description.

### 14.7.11. The Specific tab for Slider control



- Slider control lets you manipulate values of other control and present a current value between defined ranges.




Specific tab includes configuration items similarly to [Scroll bar](#). In Ticks field you can choose a way of drawing of a scale marks around the control while in Interval group you can set a distance between marks of a scale.

### 14.7.12. The Specific tab for Spin box control



- Spin box control allows you to manipulate a value taking specified ranges into consideration.




In Range group of Specific tab you should pass a range of values accepted by the control (as in [Scroll bar](#) and [Slider](#)). In Steps group you should pass a step quantity of the control. Choosing Wrapping option causes the values are wrapped i.e. after the greatest value follows the lowest one and vice versa. In Text group you can pass Prefix and Suffix appearing around displaying value of Spin box. A minimum value can be displayed as a text if you pass it in Text when min. field.

### 14.7.13. The Specific tab for List view control


No.	Property 1	Property 2
1	54884.15594	4597.2365
2	544.223	5988487.215451


- List view control presents a list of items


split into columns.



If you choose `Dynamic lists` field of `Specific` tab, you will be able to create a list of items dynamically for an object, otherwise you must pass in `Rows count` group, in `Static value` field a number of rows.




When you press the button , `Cells configuration` dialog appears. It allows you to configure particular cells of a list showing different possibilities. They are depended on the list which is static or dynamic. For the static list, all cells (number of columns multiplied by number of rows) are available while for the dynamic one - only the first row. When you choose a column of `Current column` field and double click the left mouse button on the specified row of the list, A single cell configuration dialog appears for a specified cell.



For each cell you can pass an object identifier of MIB that the cell presented a value of the object. In this case you should set `Accept incoming Pdu` field. If the identifier is built by sticking additional OID, you must choose `Accept ID string sticking` option.


In `Columns` group of `Specific` tab is presented a list of columns.




When you define a new column and press the button , `New column` dialog appears in which you should pass its title, its initial width and its kind of a text alignment and you must decide, that a column will react to clicking the mouse or you will be able to change its width.


All `columns show focus` field of `Specific` tab allows you to choose that all columns will have a focus or only the first one. `Enable column moving` field shows you if the columns can be replaced.






The button  runs `Configure sorting` window that allows you to configure a sorting for a whole object: a column number and a kind of an order (increasing or decreasing).

### 14.7.14. The Specific tab for LCD number control




Number of digit field of `Specific` tab allows you to set a number of digits that will be displayed. Degree style option shows you if a degree character is displayed or not. In Mode group you can choose one of four ways of number displaying: binary, octal, decimal, hexadecimal. If Degree style option is set, decimal number always will be displayed. Segment style group lets you choose one of three ways of digit drawing.

### 14.7.15. The Specific tab for Graph control



- Graph control presents next values of data in a form of

a time function graph.



In Range group of Specific tab you should pass limited values (a minimum and maximum value). In Title alignment and lines count you can choose a kind of a text alignment, a number of horizontal lines and distance between them. Filled graph option lets you choose that a graph will be filled with color or drawn as line. Show increase of the value instead of its own option helps you to show an increase of the value instead of the value. In Colors group you can choose colors that will be used to draw a graph, a grid and a background.


As in a case of [Progress bar](#) you can set that limited values were depended on values of MIB objects. The Graph work is shown in a description of [Progress bar](#) control.

You can also use other way to manipulate the control ranges choosing Use dynamic ranges option. It shows that limited values can be changed when are exceeded during the control work.

### 14.7.16. The Specific tab for Control light control




- Control light control shows its current state in an intuitive way.




In All values group of Specific tab you can pass a number of all possible values. For each value in Current item group, fields: Min value and Max value assign a closed range of accepted values by the item. Type field allows you to choose a kind of a shape or a graphic file that will represent this value. Depending on specified value of Type field you can pass a path to a graphic file or a line color and a color filling a specified shape and whether the shape can be drawn flatly or spatial. Flashing timer interval in 1/10 of second (0 means inactive) field lets you turn on timer with a given interval in 1/10 of seconds. A zero value causes the timer isn't run. During the work of a timer Control light alternately accepts once a given value (a value, that is currently configured) and next time a value given in Assign this value when in inactive state (when flashing) field.

Choosing Transparent control option causes that the control will be without a background (it will be transparent).

### 14.7.17. The Specific tab for Line control



- Line control shows its current state in an intuitive way.



A configuration of `Line control` is similar to [Control light](#) configuration. A main difference is a fact that a value of `Type` field is common for all the control values. In `Line width` field you should pass a control width in pixels. `Line control` as distinct from [Control light](#) always is transparent.

## 14.8. Related articles

[Network Nodes Viewer \(xdnnv\)](#)











---

# Chapter 15. Buttons the most often used in Web applications

## 15.1. The buttons meaning

There are the buttons, in the chart below, that occur the most often in Web applications. Their function in particular applications is similar and even identical sometimes. Some of the buttons can have additional functions, that were described during descriptions of the particular applications.





**Table 15.1. The buttons the most often used in Web applications**

Button	Description
	It allows you to recover to a previous page.
	It deletes an item i.e.: it closes a case, sets an event in a passive state etc.
	It allows you to get to an edition of a given item.
	It confirms an operation and makes it (i.e.: generating of a report using selected criterions).
	It allows you to get to a detailed view.
	It allows you to get to a higher level of item hierarchy.
	It opens a new window with data which are prepared for a printout.
	It allows you to get to a presentation of the graph with data for a given item ( <a href="#">Collection Browser</a> ).
	It reloads a page view.
	It accepts changed values as current one.

---

## Buttons the most often used in Web applications

---

Button	Description
	It allows you to get to a report for a given item ( <a href="#">Node Reporter</a> ).
	It lets you get to a Trap browser for a given item ( <a href="#">Trap Browser</a> ).
	It lets you get to a report browser (about cases) for a given item ( <a href="#">Recorded Operation Browser</a> ).
	It saves changes, that were done by a user.


---

# Chapter 16. Excluded IP Address Configurator


## 16.1. General

**Excluded IP Address Configurator** is Web application and it is a part of **Network Manger**. It lets you define IP addresses, that won't be scanned in order to discovering of new network devices.

## 16.2. Description



**Excluded IP Address Configurator** is one of the applications in Configuration tab. The main view of the application presents a list of IP addresses. IP address column includes a description of IP classes, that can be defined in two ways: as an IP address/subnet mask or as a regular expression. Entry type column shows a selected definition way of a given entry. User level column defines a minimum rights level of a user, that can edit a given entry or delete it. Add/Delete column lets a user add a new entry or delete an existed one. If a user logged in a portal has a 0 level of rights, a last row of the list includes fields allowing to define or add a new entry.



Entries in IP address column are links, that allow you to edit particular entries. The edited view correspond with columns in the main view of the application.

## 16.3. Related articles

[Service of Network Management Map \(dnmmsd\)](#)




---

# Chapter 17. SNMP Community Configurator

## 17.1. General

**SNMP Community Configurator** is Web application and it is a part of **Network Manager**. It allows you to configure SNMP Community entries for particular ranges of IP classes, described through regular expressions.

## 17.2. Description




**SNMP Community Configurator** is one of the applications accessible in Configuration tab. A main view of the application presents a list of regular expressions described IP classes. Regular expression describing IP addresses column includes a description of IP class defined as a regular expression. The column SNMP version shows the SNMP version used for the entry. Read community column includes community, that is used to read for a given entry, and Write community column (it is usually empty) includes community, that is used to write. These columns are only used when the entry does not apply to SNMPv3. Next six columns relate only to SNMPv3:

- Security name
- Authentication protocol: MD5, SHA
- Authentication pass phrase
- Privacy protocol: DES
- Privacy pass phrase

- Security level: no authorization, no privacy; authorization, no privacy; authorization and privacy

User level column describes a minimum rights level of a user, that can edit a given entry or delete it. Up column includes buttons, that helps a user to move a given entry up, while Down column allows to move it down. Moving of entries is an important function, because processing of the list by [dnmmsd](#) module is interrupted on the first matched entry. Add/Delete column lets a user add a new entry or delete an existed one. If a user logged in a portal has a 0 level of rights, a last row of the list includes fields allowing to define or add a new entry.



Entries in Regular expression describing IP addresses column are links, that allow you to edit particular entries. The edited view correspond with columns in the main view of the application.

## 17.3. Related articles

[Service of Network Management Map \(dnmmsd\)](#)

---

# Chapter 18. User and Group Manager

## 18.1. General

**User and Group Manager** is a Web application and it is a part of **Network Manager**. It is used to run solely [User Manager](#) and [Group Manager](#) as a kind of the interface.

## 18.2. Description



**User and Group Manager** includes only two buttons, that allow to run two applications. There are: [User Manager](#) and [Group Manager](#). It is only purpose of existing of the application.

## 18.3. Related articles

[User Manager](#)

[Group Manager](#)

# Chapter 19. User Manager

## 19.1. General

**User Manager** is a Web application and it is a part of **Network Manager**. It allows you to manage user accounts of David system. The program helps you to add new user accounts and modify existing one.

## 19.2. Description

**User Manager** allows you to manage users' accounts of David system and modify existing one. Only the users of '0' level can add new accounts.

**DAVID SYSTEM**

Weather Collections Nodes Games Reports **Users & Groups** Sys

**User Manager** version 4.1.1

No	Name	Group	Level	Groups	Default access	Can change password	Creator	Modifier	Creation	Modification	User	Group
1	root	root	3	sys	No	Yes	root	root	2006/06/28 13:22:19	2006/06/28 13:40:41	root	sys
2	root	Enhanced data collector	3		No	Yes	system	system	197001/01 01:00:00	197001/01 01:00:00		
3	root	Kernel	2	sys	No	Yes	system	system	197001/01 01:00:00	197001/01 01:00:00		
4	root	Console host	3		No	Yes	system	system	197001/01 01:00:00	197001/01 01:00:00		
5	root	David system admin	0	root	No	Yes	system	system	197001/01 00:00:00	197001/01 01:00:00		
6	root	Trinity	30	...	No	Yes	system	system	197001/01 01:00:00	197001/01 01:00:00		

Level 0 root No No Password Confirm password root root

---

Games Reports **Users & Groups** Services Configuration Documentation Logout


Can change password	Creator	Modifier	Creation	Modification	User	Group	User rights	Group rights	Other rights	Level	+Groups	Delete
Yes	root	root	2006/06/28 13:22:19	2006/06/28 13:40:41	root	sys	+	+	---	0		✖
Yes	system	system	197001/01 01:00:00	197001/01 01:00:00			---	---	---	0		✖
Yes	system	system	197001/01 01:00:00	197001/01 01:00:00			---	---	---	0		✖
Yes	system	system	197001/01 01:00:00	197001/01 01:00:00			---	---	---	0		✖
Yes	system	system	197001/01 00:00:00	197001/01 01:00:00			---	---	---	0		✖
Yes	system	system	197001/01 01:00:00	197001/01 01:00:00			---	---	---	0		✖

No Password Confirm password root root --- --- --- --- Level 0

Each account has the following fields:

- `Name` - a user's identifier;
- `Password` - a user's password;
- `Level` - a privilege level (users of '0' levels has the highest privileges while levels about higher values have every now and again lower privileges.);
- `Gecos` - a description of the account;
- `UID` - a long invisible number, that is a numerical identifier of a user,
- `Groups` - groups to which a user belongs to;
- `Default access` - it describes if a user has access to the data, that aren't specified fields with access rights;
- `Can change password` - it shows if a user can change his password;
- `Creator` - an account creator;
- `Modifier` - the last user who modified the account;
- `Creation` - the account creation time;
- `Modification` - the account modification time;
- `User` - the account owner;
- `Group` - the account group;
- `User rights` - access rights for owner's account;
- `Group rights` - access rights to the account for a group;
- `Other rights` - access rights to the account for other users;
- `Groups+` - additional groups, that have access to the account.

A default view of the application is a list of David system users. If you choose a given account, you be able to modify its properties. A view of the applications for a user of '0' level has additional options which allows you to add a new account and delete existed one.



## 19.3. Related articles

**Operation Manager:** [Graphic Notifications Server \(dgnsd\)](#)

**Operation Manager:** [Graphic Notifications Presenter \(xdgnp\)](#)

[Service of Network Management Map \(dnmmsd\)](#)

[Network Management Map \(xdnmm\)](#)

[Network Management Map Client \(dnmmc\)](#)

[Enhanced Data Collector \(dedcd\)](#)

[Group Manager](#)


# Chapter 20. Group Manager

## 20.1. General

**Group Manager** is a Web application and it is a part of **Network Manager**. It allows to manage groups of David system users. It helps to add new users' groups and modify existed groups.

## 20.2. Description

**Group Manager** helps to add new groups of users and modify existed groups. Only users of '0' level can add new groups.




The bottom table shows fields of user groups and their meaning:

**Table 20.1. Group Manager - meaning of user group fields**

Field	Description
Name	A group name.
Creator	A group creator.
Modifier	The last user who modified a group data.
Creation	Creation time of the group.
Modification	Modification time of the group.
User	An owner of the group.
Group	A group of user group.
User rights	Access rights to an owner's group.
Group rights	Access rights to a group for a group of users.
Other rights	Access rights to a group for other users.
Ulevel	A minimum user level, that can modify a group.

Field	Description
Groups+	Additional user groups, that have an access to the group.



A default view of the application is a list of David system user groups. Clicking on a selected group, you can modify its properties. The application view includes, for a user of '0' level, additional fields allowing to add new groups and remove existed groups.

## 20.3. Related articles

[User Manager](#)



---

# Chapter 21. Collection Browser

## 21.1. General

**Collection Browser** is a Web application and it is a part of **Network Manager**. It allows you to browse graphs that are created on the base of collected data from monitored devices. Moreover, the applications allow you to browse graphs generated ground of external data. The system is notified about their existence by an administrator.

## 21.2. Description




**Collection Browser** is Collections tab. The view consists of two parts. The left one is an index of available collections, where you can choose a way of data presentation and the data. The right part is a view of chosen graphs placed one by one.

### 21.2.1. The index of available collections

There are three buttons on the top, that allow to change a panel width which presents the index. There is a list below the buttons which allows to select a kind of collection, that we want to see. You can choose current collections, obsolete collections, that aren't updated or all available collections. There is an option below the kinds of collections which allows to select if the list shows variables for a given graph or not. If you select an option to show a list of accessible variables, for each graph a list with accessible variables,






that we want to show on the graph, will be available. Below the list, a selection of type devices is located. Next, the edited field is located, that allows you to entry a searching string in collections according to criterions selected above. The items, that are located below, are depended on a context of work index.

Three work contexts are accessible: browsing, searching out and an edition of selected data. The browsing is that you click on links of collection groups (they're often device equivalents). The searching lets you find needed data quickly. Passages between modes are very smooth and natural. On each stage you can select interesting data for you. During different operations previous selected data will be showed as selected to show. If you want to see all selected data, you must go to the edition mode clicking on the button . Newly selected data are remembered during a running search or through pressing any of four buttons on the bottom toolbar.

### 21.2.1.1. The toolbar buttons

Meaning of particular buttons is as follows:

**Table 21.1. Collection Browser - the toolbar buttons**

Button	Description
	Add selected collections to data remembered before and show all of them.
	Save only currently visible, selected collections and show them.
	Remembered currently visible, selected collections.
	Add selected collections to data remembered before and show a list of all remembered data.
	Delete all remembered collections.

### 21.2.1.2. Displayed data parameters





There are 5 fields allowing you to select what kind of graphs will be shown (hourly, daily, weekly, monthly or yearly). You can select graph sizes that will be drawn and time, that will be visible in the middle of the graph.

### 21.2.2. The view of collection graphs

There is a toolbar with buttons relating to all visible graphs in this part. Meaning of particular buttons is

as follows:

**Table 21.2. Collection Browser - the toolbar buttons**

Button	Description
	Refresh graphs
	Print graphs
	Zoom out graphs
	Zoom in graphs

Each graphs has additional navigational buttons that let you move after time scale. The buttons work separately for each graph.

## 21.3. Related articles

[Network Management Map \(xdnmm\)](#)

[Service of Network Management Map \(dnmmsd\)](#)

[Enhanced Data Collector \(dedcd\)](#)


# Chapter 22. Node Browser

## 22.1. General

**Node Browser** is a Web application and it is a part of **Network Manager**. It allows you to browse information about monitored devices and monitored items such as: network interfaces, BGP peers, managed items and ping objects. It also help you to control a part of items like in the case of [Network Management Map](#).

## 22.2. Description

### 22.2.1. Tree view tab



**Node Browser** is accessible through Nodes tab. A default view of the application shows two tabs - Tree view and Accounting. Below them, there is an unrolling, device list and its elements in the form of tree.

In Tree view tab 6 of 13 columns are shown by default. A user can choose which columns wants to see. Their meaning is described below:

**Table 22.1. Node Browser - Tree view columns**

Column	Description
Name	A name of group, object or item.
State	A current state of the item.
Alarm status	A current alarm status of the item.
State details	Details about a current state of the item.
Community	a result Community for the item.
Last check	Last checking time of the item.

Close the Name column, a green arrow is placed. If you push it, the list with accessible column is unrolled. The Save button saves changes.

**Table 22.2. Node Browser - the other columns of Tree view tab**

Column	Description
Is passive	It shows if the item is passive or not.
State changed	It shows time of last change of a state.
Last down state	It shows time of last change of DOWN state.
Device address	It shows a main IP address of the device.
Up time	It shows Up time of the device.
System description	It shows a system description of the device.
IP addresses	IP addresses of network interface.

### 22.2.1.1. Browsing of resources

Monitored resources can be browsed on two ways:

- browsing particular items, that are accessed as tree,
- searching items per given criterions.

The first method is easy enough, because you can click only the mouse on a list of accessible, monitored items. They should unroll until the smallest one.



The second way allows you to choose monitored items using different criterions of choice, that are accessible by the buttons placed on the top of the application. Thanks Search button, you can search interesting items using additional appearing fields and buttons.

## Node Browser

As the first, a list of different kinds of monitored devices and items is shown. You can select one kind of item from it. For example, we select Search ping objects from the list.




Close to it, there is a next list of options to choose:

- Text – you can give a text name (or its part) of the selected item,
- IP address – you can give a IP address of the selected item,
- AS number – you can give AS number of the selected item.

In the dialog window, a user writes down a searching text. The next list is the list of states - State. Three options: All, Ok, Critical are set by default. When you choose Advanced button, much more options of state list will show. Advanced button causes appearing Passive state field, that include a list of states: All, Is passive and Is not passive.

When you select Search managed items option from the list of accessible items, additional list will be shown with managed item group at choice. The list of current, defined managed item groups can show as below:













When we give all our criteria of choice and press Search button, data which interests us will be shown. Add search button allows you to add to the displayed list next items from the list of accessible


item groups, i.e. managed items.

Tree view tab allows you to search resources using buttons of its main manu. Their meaning is described below:

**Table 22.3. Node Browser - Tree view buttons**


Button	Description
	It refresh data browsing by a user currently.
	It allows to search items per using additional displayed field and buttons.
	It displays a list of items at choice.
	It allows to select and unselect items from the list.
	It lets you set alarms.
	It lets you reset the item state to OK value.
	It opens Discover device window in which you can give a domen name of the device or its IP address.
	It lets you print selected data.
	It explores selected data to .csv file.
	It opens a configure window of Tree view tab. It includes options influencing such browsing mode as searching mode of the tab.

### 22.2.1.2. Additional options of Tree view tab



Additional menu including the other options, is accessible close to the item name. We can see on the picture data of battery status of ups. Both close to ups's name and Battery status item, the green arrows are placed. When you click on the arrow, the menu of options is unrolled. The menu will be

displayed with different options for a given item depending on context.



The options of the context menu are described below:

- Show only this device – it only shows devices as a result of searching,
- Show SNMP Trap report – it shows a report about SNMP Traps for the item,
- Show case report – it shows a report about cases for the item,
- Set parent... - it opens a window to choose a new parent (a new container),
- Show state report – it shows a report about changes of states for the item,
- Scan now – it sends a request to scan a new device,
- Check now – it sends a request to poll the item of device right now,
- Turn passive state on – it sets a passive state for the item,
- Add to accounting report – it adds an item to the report about accounting (Accounting tab).

If you click on the item name, in the main view of the application, the window with additional information about it is displayed.

For example, it is a detailed view of the network interface.




[-]  Devices (2)	
[-] <input type="checkbox"/> F...	Ok
[-]  Network interfaces (2)	
<input type="checkbox"/> eth0	Ok  On
<input type="checkbox"/> Network interface	
<input checked="" type="checkbox"/> LO	ID: 773
<input checked="" type="checkbox"/> Computer	Device: F...
<input checked="" type="checkbox"/> Router	Description: eth0
<input checked="" type="checkbox"/> Atm sw	Alias:
<input checked="" type="checkbox"/> Ethernet	IfIndex: 2
<input type="checkbox"/> <input type="checkbox"/> p...	Admin state: Up
<input checked="" type="checkbox"/> Net	Oper state: Up
<input checked="" type="checkbox"/> -Mp	Speed: 100 MBits/sec
<input checked="" type="checkbox"/> -Mp	State: Ok
<input checked="" type="checkbox"/> Fan	Alarm status:  On
<input checked="" type="checkbox"/> Fou	Alarm counter:
<input checked="" type="checkbox"/> Fou	Is passive: No
<input checked="" type="checkbox"/> Mpl	Last check: 2008/11/06 00:59:49 (11:30:08 ago)
<input checked="" type="checkbox"/> Pow	Last state change: 2008/11/06 00:24:42 (12:05:15 ago)
<input type="checkbox"/> Last down state:	Never
<input type="checkbox"/> Ip addresses:	192.168.80.20
<input type="checkbox"/> Customer:	





For example, it is a detailed view of the managed item.

Ethernet switches (1)	
<input type="checkbox"/> p sw <span style="color: green;">Ok</span>	
Network interfaces (39)	
Mpls Ldp (5)	
<input type="checkbox"/> 10.10.0.1.0.0.1 <span style="color: red;">Critical</span> <span style="color: green;">On</span> Admin status: <span style="color: green;">enable</span>	
<b>Managed item</b>	
<input type="checkbox"/> ID:	2593
<input type="checkbox"/> Device:	p sw
<input type="checkbox"/> Index:	10.10.0.1.0.0.1
<input type="checkbox"/> Protocol version:	1
<input type="checkbox"/> Admin status:	<span style="color: green;">enable</span>
<input type="checkbox"/> Oper status:	<span style="color: red;">disabled</span>
<input type="checkbox"/> Label distribution method:	downstreamUnsolicited
<input type="checkbox"/> Label retention mode:	liberal
<input type="checkbox"/> Path vector limit:	
<input type="checkbox"/> Hop counter limit:	
<input type="checkbox"/> Transport address:	interface
<input type="checkbox"/> Uses targeted peer:	No
<input type="checkbox"/> Peer address type:	unknown
<input type="checkbox"/> Peer address:	
<input type="checkbox"/> Label type:	generic
<input type="checkbox"/> Discontinuity time:	0 sec.
<input type="checkbox"/> State:	<span style="color: red;">Critical</span>
<input type="checkbox"/> Alarm status:	<span style="color: green;">On</span>
<input type="checkbox"/> Alarm counter:	1960
<input type="checkbox"/> Is passive:	No
<input type="checkbox"/> Last check:	2008/11/06 00:59:49 (11:41:17 ago)
<input type="checkbox"/> Last state change:	2008/11/06 00:24:42 (12:16:24 ago)
<input type="checkbox"/> Last down state:	2008/11/06 00:59:49 (11:41:17 ago)
<input type="checkbox"/> Customer:	


For example, it is a detailed view of the ping object.

Ping object	
ID:	8
Name:	sw
IP:	192.168.100.11
Status:	<b>Down</b>
Minimum RTT:	0.000 ms
Average RTT:	0.000 ms
Maximum RTT:	0.000 ms
Responses:	<b>0%</b>
State:	<b>Critical</b>
Alarm status:	 Off until Ok
Alarm counter:	2544
Is passive:	No
Last check:	2008/11/06 01:01:10 (12:01:38 ago)
Last state change:	2008/11/06 00:24:40 (12:38:08 ago)
Last down state:	2008/11/06 01:01:10 (12:01:38 ago)


For example, it is a detailed view of the BGP peer.

<input type="checkbox"/>	 lo (IP: 212.101.225.2, AS8501) 	Ok	 On
<b>AS Bgp peer</b>			
<input type="checkbox"/>	<b>ID:</b>	345	
<input type="checkbox"/>	<b>Device:</b>	gw1	
<input type="checkbox"/>	<b>Description:</b>	gw	
<input type="checkbox"/>	<b>Remote IP:</b>	212.101.225.2	
<input type="checkbox"/>	<b>Local IP:</b>	212.101.225.2	
<input type="checkbox"/>	<b>Remote AS:</b>	8501	
<input type="checkbox"/>	<b>Admin state:</b>	Start	
<input type="checkbox"/>	<b>Oper state:</b>	Established	
<input type="checkbox"/>	<b>Local interface:</b>	at-0/0/0.5 (=== gw1 - gw ===)	
<input type="checkbox"/>	<b>State:</b>	Ok	
<input type="checkbox"/>	<b>Alarm status:</b>	 On	
<input type="checkbox"/>	<b>Alarm counter:</b>		
<input type="checkbox"/>	<b>Is passive:</b>	No	
<input type="checkbox"/>	<b>Last check:</b>	2008/11/06 13:09:48 (2 min. 55 sec. ago)	
<input type="checkbox"/>	<b>Last state change:</b>	2008/10/30 14:11:29 (6 days 23:01:14 ago)	
<input type="checkbox"/>	<b>Last down state:</b>	2007/09/18 10:08:54 (415 days 04:03:49 ago)	

For example, it is a detailed view of the device.

Routers (10)	
gw 	
<b>Router</b>	
<b>ID:</b>	773
<b>Name:</b>	gw
<b>Parent:</b>	
<b>Device IP:</b>	
<b>Uptime:</b>	44 days 18:55:45 (2008/09/22 19:54:10)
<b>System name:</b>	default@e
<b>System description:</b>	Juniper Networks, Inc. m20 internet router, UTC builder@rahu.juniper.net:/volume/build/ Build date: 2008-08-12 23:18:32 UTC Copyright (c) 1996-2008 Jun
<b>State:</b>	Was critical
<b>Is passive:</b>	No
<b>Last check:</b>	2008/11/06 13:49:56 (4 min. 0 sec. ago)
<b>Last update:</b>	2008/11/06 12:51:33 (01:02:23 ago)

## 22.2.2. Accounting tab



Accounting tab shows number of octets (bytes) and packets sending by network interfaces. It allows to count sending data from defined clients. A view of the application is divided on two parts. In the first one, traffic on interfaces is presented and in the second one - traffic to clients.

If you want to add network interfaces to the report about counting of traffic, you should select the item in Tree view tab and Add to accounting report option, that is accessible in menu for a given item. Then, you should choose Accounting tab and give time range or not, but then the application will set time range by default, and it counts traffic on selected interfaces from the beginning of the day. Then, you may press Save button to save changes.

If you choose items for report and time range, you should press Count button.

No Device	Interface	Start	Stop	Total octets	Total packets	Total octets (%)	Total packets (%)
1	gw ael	2008/10/02 00:00:00	2008/11/04 23:59:59	158.26TB	263.06GP	31.67%	31.47%

Data are displayed in particular columns which are described below:

- Device – a name of the network device;
- Interface – a name of the network interface;
- Start – time of the first data which was appeared in selected time range;
- Stop – time of the last data which was appeared in selected time range;
- Total octets – a number of sent octets of data;
- Total packets – a number of sent packets of data;
- Total octets (%) – percent share of octets in the sum of all the list;
- Total packets (%) - percent share of packets in the sum of all the list;

In the Interface column is button, that displays `Selected columns` window with columns accessible to show in the main view of the application. Description of the columns which aren't shown by default, is as follows:

- Records – a number of accounting records,
- Fixed records – a number of fixed, accounting records,
- Input octets – a number of input octets,
- Output octets – a number of output octets,
- Input packets – a number of input packets,
- Output packets – a number of output packets,
- Input octets (%) - percent share of input octets in the sum of all the list,
- Output octets (%) - percent share of output octets in the sum of all the list,
- Input packets (%) - percent share of input packets in the sum of all the list,
- Output packets (%) - percent share of output packets in the sum of all the list.

Accounting data for clients are placed in the second part of the main view of the application. In this way, you can add selected clients to the list using `Configuration` tab, and next `Customers` field. It runs **Customer Configurator** application, where you'll find lists of clients and their groups. You can choose some client and look its detailed view.


Customer details	Additional groups	Network interfaces	Managed items
Name:	A	A	
Identifier:	01-1	01-1	
Customer group:	Edukacja	Edukacja	
Creator:	root		

Then, you can select \$ icon. The client will be added to the list in `Accounting` tab of **Node Browser** application automatically. Then you should press `Count` button to show results of accounting data for selected clients.

## Node Browser

Customer accounting for a period: 2008/11/07 00:00:00 - 2008/11/07 16:00:00 (duration: 16:00:00)									
No	Name	Identifier	Group	Start	Stop	Total octets	Total packets	Total octets (%)	Total packets (%)
C									
1		03-1	Edukacja	2008/11/07 00:00:00	2008/11/07 15:59:59	4.47GB	6.27MP	61.26%	54.80%
C									
2		04-1	Edukacja	2008/11/07 00:00:00	2008/11/07 15:59:59	2.82GB	5.15MP	38.68%	45.03%
D									
3	D	19-1	Komercja	2008/11/07 00:00:00	2008/11/07 15:59:59	3.94MB	20.05KP	0.05%	0.18%

Like in Tree view tab, in Accounting tab, Reload button refreshes a current view of the application, Print button - prints a current view of the application, Export button - exports data to .csv file, and Configure button - sets additional options of the application. If you press the button, the Configure window is displayed and it lets you choose the following values:



- Printed units field lets you choose the values: Best units for value, Same values, Kilo, Mega, Giga, Tera;
- Number decimal separator field has the values: Dot (.), Comma (,);
- Bars field has two options: Show, Hide;
- Fix rows containing errors field has two options: Yes and No.

## 22.3. Related articles

[Network Management Map Client \(dnmmc\)](#)

[Network Management Map \(xdnmm\)](#)

[Service of Network Management Map \(dnmmsd\)](#)



---

# Chapter 23. Node Reporter

## 23.1. General



**Node Reporter** is a Web application and it is a part of **Network Manager**. It gives an access to reports about particular monitored devices.

## 23.2. Description

### 23.2.1. Specification of searching criterions

#### 23.2.1.1. Default view of the application




**Node Browser** is accesible through Nodes. It's created by the following groups: Pings, Network interfaces, BGP peers and Managed items. Each group includes fields, that in characteristic way for a given item type allow to specific criterions of its search. Clicking on the button  lets you run a searching process for a given item. Clicking on the button  allows you to go to detailed view of selected item group.

All groups includes Show/hide matched filed, that can take on two states: Show or Hide. The first

state means, that items realising searching criterions, are shown while the second one, that the criterions aren't shown. As a result of search you receive an item list about which you can receive detailed reports.

All groups also include `Show only items with DOWN states` field, that show, whether a final report will be generated for all selected items, or for the items from among selected one, that in a given period of time were selected at least for once in DOWN state.

### 23.2.1.2. Pings group

<b>Pings</b> 	
Name	<input type="text"/>
IP	<input type="text"/>
Group	<input type="text" value="-- Don't mind --"/>
Show only items with DOWN states	<input type="text" value="No"/>
Show/hide matched	<input type="text" value="Show"/>


The group includes `Name` field in which you can give a ping object description (given by an administrator) or its part. `IP` field allows you to give IP address (or its part) of searched ping object. `Group` field allows you to select a ping object group.

### 23.2.1.3. Network Interfaces group

<b>Network interfaces</b> 	
Description	<input type="text"/>
Interface	<input type="text"/>
Deleted	<input type="text" value="Hide"/>
Show only items with DOWN states	<input type="text" value="No"/>
Show/hide matched	<input type="text" value="Show"/>


The group includes `Description` field in which you can give a network interface description (given by an administrator) or its part. In `Interface` field you can select an interface name or its part. `Deleted` field shows, if interfaces matched as deleted will be searched.

### 23.2.1.4. BGP peers group

BGP peers 	
Description	<input type="text"/>
Peer IP address	<input type="text"/>
Peer AS	<input type="text"/>
Show only items with DOWN states	No <input type="button" value="v"/>
Deleted	Hide <input type="button" value="v"/>
Show/hide matched	Show <input type="button" value="v"/>

The group includes `Description` field in which you can give a BGP peer description (given by an administrator) or its part. `Peer IP address` field allows you to give an IP address (or its part) of a searched BGP peer. In `Peer AS` field you can give a BGP peer number. `Deleted` field shows, if BGP peers matched as deleted will be searched.

### 23.2.1.5. Managed items group

Managed items 	
Text	<input type="text"/>
Source device	--- Don't mind --- <input type="button" value="v"/>
Group	--- Don't mind --- <input type="button" value="v"/>
Deleted	Hide <input type="button" value="v"/>
Show/hide matched	Show <input type="button" value="v"/>

The group includes a field `Text` in which the user can give a searched string. `Source device` field lets choose a device which managed items will be searched, while the fields `Group` lets the user select a group which managed items belong to. The field `Deleted` tells whether also items marked as deleted will be searched.

## 23.2.2. A specification of report components for given items

The view is divided on two parts. The top one includes an items list for which a report will be prepared. The bottom one includes a report configuration. Depending on a kind of reports for which a report will be generated, a list of them will be have a different form but a bottom part of the view will be the same. There is a detailed report configuration. Reports will be prepared for items selected in the top part. Particular groups of a configured report part describe the single report components, that will be select during a report configuration (i.e. Status shares, Logs). Common group includes parameters common for other groups (i.e. time range of a report). Time range group includes parameters relating to a whole report.

### 23.2.2.1. Status shares group

The group corresponds with the report part, that shows a percentage share of particular states which a given item can take on. Graph's width and Graph's height fields let you specify width and height of a graph, that shows a percentage share of particular states.

### 23.2.2.2. Status graph group

Status graph

Each period occupies

Graph's width

The group corresponds with the report part, that shows state changes in a specified period of time which a given item can take on. Each `period occupies` field allows you to select a minimum scale of time axis, and `Graph's width` and field let you specify a graph width showing state changes in a specified period of time.

### 23.2.2.3. Responses group

Responses

Graph's width

Graph's height

Min RTT  Avg RTT

Max RTT  Percent of responses

The group only concerns ping objects and it isn't shown default in the report, because it is on experimental stage. The fields `Graph's width` and `Graph's height` allow you to specify a graph width and height, that shows received messages for a ping object. The fields `Min RTT`, `Avg RTT`, `Max RTT` and `Percent of responses` helps you to choose a kind of data, that will be shown on the graph.

### 23.2.2.4. Logs group

Logs

Results per page

The group corresponds with the report part, that shows entries about particular states of a given item. `Results per page` field allows you to describe a maximum number of entries, that will be presented for once.

### 23.2.2.5. Time range group


Time range

Time range


Year  Month  Day  Hour  Minute  Period

The group needn't be selected, because it concerns time range of a whole report. The time range can be specified on two ways: through choosing of time range, that lasts to a current moment or through choosing a given date and time in combination with a selected time range (i.e.: 1 day, 2 days, 1 week, etc.).

### 23.2.3. Generated report



The picture shows an exemplary report view for a single item, that consists of three groups (Status shares, Status graph and Logs). The beginning of the report, for each selected entry, a heading with description and link to [Node Browser](#) (showing the item) is placed. There is also a time range for which the report was prepared.



There is a difference in the look of the report prepared for managed items. It includes information regarding general parameters, which all items have, and parameters specific to the origin managed item group.

## 23.3. Related articles

[Service of Network Management Map \(dnmmsd\)](#)

[Network Management Map \(xdnmm\)](#)

[Network Management Map Client \(dnmmc\)](#)


---

# Chapter 24. Notification Recipient Configurator

## 24.1. General


**Notification Recipient Configurator** is a Web application and a part of **Network Manager**. It allows to make connection between `community` values and e-mail recipient. Thanks this, a part of David system scripts can decide, where notification send, if it is needed.

## 24.2. Description



**Notification Recipient Configurator** is one of applications accessible in Configuration tab. A main view of the application presents a list of notification recipients. `Community` column includes a string which is used to describe e-mail address of notification recipient, that is included in `E-mail` column. A notification recipient, for a given `Community`, can be a single e-mail address or their list, that elements are separated by commas. `Send short messages` column describes, if messages, sent to the recipient, are a short form or normal. The short form usually includes only a subject of the message and it can use to sent sms. `User level` column defines a minimum rights level of the user, that can edit a given entry or delete it. `Add/Delete` column lets a user add a new entry or delete an existed one. If a user logged in the portal has got a 0 level of rights, a last row of the list includes fields allowing to define and add a new entry.





Entries in Community column are links, that allow you to edit particular entries. The edited view correspond with columns in the main view of the application.

## 24.3. Related articles

[Service of Network Management Map \(dnmmsd\)](#)

# Chapter 25. Web Module Configurator

## 25.1. General

**Web Module Configurator** is a Web application and it is a part of **Network Manager**. It allows to manage access rights of David system users to particular modules, i.e. Web applications. In this way, you can limit access to a part of Web interfejs of David system for some users.

## 25.2. Description

The screenshot shows the 'Web Module Configurator' interface within the 'DAVID SYSTEM' environment. The interface includes a navigation menu with options like Weather, Collection, Notes, Cases, Reports, Users & Groups, Services, Configuration, and Documentation. The main content area displays a table with 21 rows, each representing a different web module. The table columns include: No., Name, Creator, Modifier, Creation, Modification, User, Group, User rights, Group rights, Other rights, Ulevel, and +Groups.

No.	Name	Creator	Modifier	Creation	Modification	User	Group	User rights	Group rights	Other rights	Ulevel	+Groups
1	Collection Browser	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
2	Excluded IP Address Configurator	system	system	2006/04/30 18:09:22	2006/04/30 18:09:22	system	system	rwx	rwx	rwx	0	
3	GDC-Stat Configurator	system	system	2006/04/30 18:09:24	2006/04/30 18:09:24	system	system	rwx	rwx	rwx	0	
4	Group Manager	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
5	IP Address Configurator	system	system	2006/04/30 18:09:22	2006/04/30 18:09:22	system	system	rwx	rwx	rwx	0	
6	MAC Address Configurator	system	system	2006/04/30 18:09:22	2006/04/30 18:09:22	system	system	rwx	rwx	rwx	0	
7	Message UPS Contact Configurator	system	system	2006/04/30 18:09:22	2006/04/30 18:09:22	system	system	rwx	rwx	rwx	0	
8	Module Configurator	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
9	Node Browser	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
10	Node Report Browser	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
11	Notification Recipient Configurator	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
12	Pending Operation Browser	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
13	Recorded Operation Browser	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
14	Report Browser	system	system	2006/04/30 18:09:20	2006/04/30 18:09:20	system	system	rwx	rwx	rwx	0	
15	Report Manager Configurator	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
16	Service Monitor	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
17	SNMP Community Configurator	system	system	2006/04/30 18:09:22	2006/04/30 18:09:22	system	system	rwx	rwx	rwx	0	
18	Trap Browser	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
19	User and Group Manager	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
20	User Manager	system	system	2006/04/30 18:09:21	2006/04/30 18:09:21	system	system	rwx	rwx	rwx	0	
21	Web Module Configurator	system	system	2006/04/30 18:09:22	2006/04/30 18:09:22	system	system	rwx	rwx	rwx	0	

**Web Module Configurator** allows to manage access rights to particular modules of David system Web interface. A main view of the application presents a list of accessible Web applications with their properties. The following table shows fields, that each application has got:

**Table 25.1. Web Module Configurator - meaning of the application fields**

Field	Description
Name	The application name.
Creator	A data creator of the application.
Modifier	The last user who modified data of the application.

Field	Description
Creation	Creation time of data concerning the application.
Modification	Modification time of data concerning the application.
User	Owner's application.
Group	A group of application users.
User rights	Access rights to the application for an owner.
Group rights	Access rights to the application for a user group.
Other rights	Access rights to the application for other users.
Ulevel	A minimum user level, that can modify data of the application.
Groups+	Additional user groups, that have access to the application.



Clicking on an item name from a list of accessible applications opens a detailed view to the selected application. The view allows to edit properties of a given application.

## 25.3. Related articles

[User Manager](#)

[Group Manager](#)

# Chapter 26. Service Monitor

## 26.1. General

**Service Monitor** is a Web application and it is a part of **Network Manager**. It presents a list of daemons (services), that are managed by [Service Manager](#), and a list of installed products of David system.

## 26.2. Description

The screenshot displays the 'Service Monitor' web application. The top navigation bar includes 'Header', 'Collections', 'Nodes', 'Cases', 'Reports', 'Network services', 'Users & Groups', 'Services', 'Configuration', and 'Documentation'. The main content area is titled 'Service Monitor' and contains two tables:

No	Name	Description	State	PID	Last checked	Last started	Last stopped	Last failed	Starts	Stops	Fails
1	damdbnd	Association database unit	RUNNING	14593	2007/08/18 13:48:51	2007/08/14 10:18:24	2007/08/14 00:16:15	Never	4	3	0
2	damcmd	Cases service unit	RUNNING	9921	2007/08/18 13:48:51	2007/08/16 12:53:05	2007/08/16 12:50:51	Never	13	12	0
3	damcmdpland	Scmp data analyzer	STOPPED	Never	Never	Never	Never	Never	0	0	0
4	damcmdpland	Scmp traps analyzer	RUNNING	7428	2007/08/18 13:48:51	2007/08/15 12:43:45	2007/08/13 12:22:52	Never	2	1	0
5	dbband	SQL database analyzer manager	RUNNING	7439	2007/08/18 13:48:51	2007/08/15 12:44:04	2007/08/13 12:21:30	Never	8	7	0
6	dadcd	Enhanced data collector	RUNNING	9758	2007/08/18 13:49:01	2007/08/16 12:51:18	2007/08/16 12:50:56	2007/08/08 10:42:00	13	11	1
7	dgnd	Graphic notifications server	RUNNING	17680	2007/08/18 13:48:55	2007/08/04 22:50:08	Never	Never	1	0	0
8	damcmd	Service of network management map	RUNNING	9755	2007/08/18 13:48:58	2007/08/16 12:51:14	2007/08/16 12:51:01	2007/08/06 09:58:55	16	13	2
9	damcmd	Network service monitor	RUNNING	7431	2007/08/18 13:48:25	2007/08/15 12:43:51	2007/08/13 12:21:15	Never	5	2	0
10	damcmd	Report manager	RUNNING	8835	2007/08/18 13:48:51	2007/08/10 14:22:58	2007/08/10 14:22:45	Never	2	1	0
11	damcmd	Syslog monitor	RUNNING	17681	2007/08/18 13:48:55	2007/08/04 22:50:08	Never	Never	1	0	0
12	damcmd	Slow query executor	RUNNING	7434	2007/08/18 13:48:28	2007/08/15 12:43:58	2007/08/13 12:22:14	Never	5	2	0
13	damcmd	Events (traps and information) receiver	RUNNING	9928	2007/08/18 13:48:54	2007/08/16 12:53:08	2007/08/16 12:50:46	Never	12	11	0

No	Name	Version	Installed	Updated
1	Network Manager	2.0.0	2005/01/08 10:32:58	2007/08/05 20:53:29
2	Notification Processor	0.18.0	2005/01/08 10:34:48	2007/08/05 20:54:04
3	Operation Manager	0.19.0	2005/01/08 10:35:51	2007/08/05 20:54:35
4	Report Manager	1.0.0	2005/01/08 10:37:53	2007/08/05 20:55:05
5	Service Monitor	0.2.0	2005/01/01 12:33:58	2007/08/05 12:45:37
6	SQL Database Backup Manager	0.1.0	2005/01/08 10:40:48	2005/01/00 10:00:00
7	Syslog Monitor	0.1.0	2005/01/08 10:41:24	2005/01/00 10:00:00

**Service Monitor** lets see a list of daemons (services), which are working on the server and are managed by [Service Manager](#). It also allows to see a list of installed products of David system on the server. The main view of the application is divided into two parts. The first one `Monitored services` includes a list of David system monitored services. In the table below columns of the application part are described:

**Table 26.1. Service Monitor - meaning of the application fields**

Field	Description
Name	A name of executable program.
Description	The application description.
State	It shows, if the application is run or not.
PID	An identifier of the application process.

Field	Description
Last Checked	A time of last checked, if a given application is working.
Last started	A time of last running of the application.
Last stopped	A time of last stopped of the application.
Last fallen	A last time, when <a href="#">Service Manager</a> noticed, that a given application doesn't work, though it was started.
Starts	A number of the application starts.
Stops	A number of the application stops.
Falls	A number of the application work failures.

The second part of the application shows a list of David system logged in products. In the part a user can see a product name, its version, installation time and last update.

## 26.3. Related articles

[Service Manager](#)

[Client of Service Manager \(dsc\)](#)

---

# Chapter 27. Customer Configurator

## 27.1. General

**Customer Configurator** a Web application and it is a part of **Network Manager**. It allows to create a list of clients and their groups and generate accounting reports of transferred data, on the base of them

## 27.2. Description



No	Delete	Name	Identifier	Customer group	Creator	Modifier	Creation	Modification	User	Group	User rights	Group rights	Other rights	Ulevel	+Groups
1	<input type="checkbox"/>	A	017	Komercja	root	krzysiek	2008/05/12 13:01:08	2008/05/19 13:51:46	krzysiek	sys	rwX	r-x	--	2	
2	<input type="checkbox"/>	B	018	Komercja	root	krzysiek	2008/05/12 13:02:47	2008/05/19 13:52:11	krzysiek	sys	rwX	r-x	--	2	
3	<input type="checkbox"/>	D	02	Komercja	root	krzysiek	2008/05/12 12:59:20	2008/07/11 09:26:05	krzysiek	sys	rwX	r-x	--	2	
4	<input type="checkbox"/>	P	019	Komercja	root	krzysiek	2008/05/12 13:02:54	2008/05/19 13:52:48	krzysiek	sys	rwX	r-x	--	2	

**Customer Configurator** is accessible in Configuration tab by pressing of Customers button. The application has two tabs: Customers and Customer groups.

### 27.2.1. Customers tab

This part of the applications allows to create a list of customers.

If you want to add a new client to the list, you should press New button. Then, a dialog window displays itself to add new clients. You should give a client's name, choose identifier and group, if it exists, and set access rights for users and user groups.

# Customer Configurator version 0.3.0

**Customers****Customer groups****Customer details****New customer details****Name:****Identifier:****Customer group:**==== None ==== ▾**Creator:****Modifier:****Creation:****Modification:****User:**oper ▾**Group:**root ▾**User rights:**... ▾**Group rights:**... ▾**Other rights:**... ▾**Ulevel:**Level 0 ▾**Save**



If you click on a client, you select its edition. For each entry, 4 tabs are accessible: Customer details, Additional groups, Network interfaces, Managed items.

And here, in Customer details, you can change an entry name, its identifier, access rights for groups and users.

# Customer Configurator version 0.3.0

**Customers**

**Customer groups**



**Customer details**

**Additional groups**

**Network**

<b>Name:</b>	M	<input type="text" value="M"/>
<b>Identifier:</b>	22	<input type="text" value="22"/>
<b>Customer group:</b>	Komercja	<input type="text" value="Komercja"/>
<b>Creator:</b>	root	
<b>Modifier:</b>	krzysiek	
<b>Creation:</b>	2008/05/12 12:58:38	
<b>Modification:</b>	2008/05/19 13:53:55	
<b>User:</b>	krzysiek	<input type="text" value="krzysiek"/>
<b>Group:</b>	sys	<input type="text" value="sys"/>
<b>User rights:</b>	rwx	<input type="text" value="rwx"/>
<b>Group rights:</b>	r-x	<input type="text" value="r-x"/>
<b>Other rights:</b>	---	<input type="text" value="---"/>
<b>Ulevel:</b>	Level 2	<input type="text" value="Level 2"/>

Save

Save as new


In Additional groups tab you can add a new group and set it access rights.



In `Network interfaces` group, you can add selected network interfaces to the client. In this case a list of monitored devices is accessible and using it, you can choose a device and its network interfaces.




In `Managed items` tab, you can add managed item to the client.



The buttons of the main view allows you to do new actions. Besides adding a new entry, \$ button adds a selected client to the accounting report of `Node Browser` application. The green arrows lets you move between clients in order of the client list. The middle arrow moves us to the main view of the application. The red button deletes a client from the list which is looked currently.



The application lets you search clients according to their names, identifiers or groups. In this case, you should use Search . . . button. After finish searching you should use Exit search button.



Columns of the client list are described below:

Customers															< prev	1	next >
No	Delete	Name	Identifier	Customer group	Creator	Modifier	Creation	Modification	User	Group	User rights	Group rights	Other rights	Ulevel	+Groups		
1	<input type="checkbox"/>	SA	19	Komercja	root	krzysiek	2008/05/12 13:02:54	2008/05/19 13:52:48	krzysiek	sys	rwX	r-x	---	2			

**Table 27.1. Customer Configurator - columns of the application**

Column	Description
Delete	It marks a client to delete.
Name	A name of the client.
Identifier	An identifier of the client.
Customer group	A group to which a client belongs to.
Creator	A creator of entry about the client.
Modifier	A modifier of entry about the client.
Creation	Creation time of entry about the client.
Modification	Last, modification time of entry about the client.
User	An owner's name of entry about the client.
Group	A group of entry about the client.
User rights	Access rights to entry about the client for its owner.
Group rights	Access rights to entry about the client for group of users.
Other rights	Access rights to entry about the client for the other users.
Ulevel	A minimum level of the user, that can modify an entry about the client.
Groups+	Additional groups of users, that can an access to entry about the client.

If you click on an item name of the accessible application list, you can see a detailed view of selected application. The view lets you change properties of selected application.

### 27.2.2. Customer groups tab

Customer grouptab creates groups of clients. Meaning of columns of the tab is agreed with meaning of columns of Customers tab with the exception of Num of customers column which shows a number of clients, that are included in this group.

Customer Configurator version 0.3.0														
Customer groups														
No	Delete	Name	Num of customers	Creator	Modifier	Creation	Modification	User	Group	User rights	Group rights	Other rights	Ulevel	+Groups
1	<input type="checkbox"/>	<a href="#">edukacja</a>	3	kasia	kasia	2008/11/14 13:05:33	2008/11/14 13:11:33	kasia	sys	rwX	---	---	2	
2	<input type="checkbox"/>	<a href="#">komercja</a>	2	kasia	kasia	2008/11/14 13:03:36	2008/11/14 13:11:26	kasia	sys	rwX	---	---	2	

New button adds a new group. If you press it, the dialog window Customer group details is opened, where you should give a name of client group, an entry owner and set access rights.

# Customer Configurator version 0.3.0

**Customers****Customer groups****Customer group details****New customer group details**

<b>Name:</b>	<input type="text" value="domy studeckie 1-8"/>
<b>Number of customers:</b>	5
<b>Creator:</b>	
<b>Modifier:</b>	
<b>Creation:</b>	
<b>Modification:</b>	
<b>User:</b>	<input type="text" value="kasia"/>
<b>Group:</b>	<input type="text" value="root"/>
<b>User rights:</b>	<input type="text" value="rwx"/>
<b>Group rights:</b>	<input type="text" value="r-x"/>
<b>Other rights:</b>	<input type="text" value="..."/>
<b>Ulevel:</b>	<input type="text" value="Level 7"/>

**Save**

If you click a name of client group, in the main view of the application, the dialog window is opened, that is consisted of two tabs: `Customer grup details` and `Additional groups`.

## Customer Configurator version 0.3.0

**Customers**
**Customer groups**








**Customer group details**
**Additional groups**

<b>Name:</b>	komerccja	<input type="text" value="komerccja"/>
<b>Number of customers:</b>	2	
<b>Creator:</b>	kasia	
<b>Modifier:</b>	kasia	
<b>Creation:</b>	2008/11/14 13:03:36	
<b>Modification:</b>	2008/11/14 13:11:26	
<b>User:</b>	kasia	<input type="text" value="kasia"/>
<b>Group:</b>	sys	<input type="text" value="sys"/>
<b>User rights:</b>	rwx	<input type="text" value="rwx"/>
<b>Group rights:</b>	---	<input type="text" value="---"/>
<b>Other rights:</b>	---	<input type="text" value="---"/>
<b>Ulevel:</b>	Level 2	<input type="text" value="Level 2"/>

In the first tab you can change data concerning a group. You can change a name of the client group and access rights. Green arrows lets you move between groups of clients in order of the list. The second tab `Additional groups` lets you add additional group to the group of clients and set access rigthe for it.



## 27.3. Related articles

[Node Browser](#)

[Enhanced Data Collector \(dedcd\)](#)